EdgeStore NAS400 User Manual

Version 1.0

Copyright

© 2007 Edge10 Corporation Limited. All Rights Reserved.

Copyright by Edge10 Corporation Limited. (Edge10). No part of this manual may be reproduced or transmitted in any form without the expressed, written permission of Edge10.

Important data protection information

You should back up all data before installing any drive controller or storage peripheral. Edge10 is not responsible for any loss of data resulting from the use, disuse or misuse of this or any other Edge10 product.

Notice

Although Edge10 has attempted to ensure the accuracy of the content of this manual, it is possible that this document may contain technical inaccuracies, typographical, or other errors. Edge10 assumes no liability for any error in this publication, and for damages, whether direct, indirect, incidental, consequential or otherwise, that may result from such error, including, but not limited to loss of data or profits.

Edge10 provides this publication “as is” without warranty of any kind, either express or implied, including, but not limited to implied warranties of merchantability or fitness for a particular purpose.

The published information in the manual is subject to change without notice. Edge10 reserves the right to make changes in the product design, layout, and driver revisions without notification to its users.

This version of the *User Manual* supersedes all previous versions.

Recommendations

In this *User Manual*, the appearance of products made by other companies, including, but not limited to software, servers, and disk drives, is for the purpose of illustration and explanation only. Edge10 does not recommend, endorse, prefer, or support any product made by another manufacturer.

Contents

Chapter 1: Introduction to EdgeStore 1
About This Manual 1
Architecture 2
Protocol Support 2
Key Benefits 2
Specifications 3
Compatible Backup Software 4
Client OS Support 4
Browser Support 4

Chapter 2: Installation and Setup 5
Unpacking the EdgeStore NAS400 5
Installing Disk Drives 7
Connecting to the Network 7
Connecting the Power 8
Installing the Software 8
Optional. Selecting Your Network 12
Setting up the EdgeStore 13
Connecting to EASM 17
Browser Support 17
Finding the EdgeStore's IP Address 17
EASM in your Browser 18
EASM in SmartSYNC 19
Shutting Down the EdgeStore 20

Chapter 3: Connecting to the EdgeStore 21
Setting up a Network Drive on a Windows PC 21
Setting up a Network Drive on a UNIX or Linux PC 24
Setting up a Network Drive on a Macintosh PC 27
Connecting a USB Printer to EdgeStore 31
Setting up the Print Server on EdgeStore 32
Setting up Windows Printing 32
Setting up Linux Printing 34
Setting up Macintosh Printing 37
Connecting a USB Drive 39
Disconnecting a USB Drive 42

Chapter 4: One Touch Backup 43
Enabling One Touch Backup 43
Creating a Backup Schedule 44
Performing a One Touch Backup 45
Viewing Your Backup Files 46
Restoring Your Backup Files 47

Chapter 5: SmartSYNC 49
Opening the SmartSYNC Window 49
Choosing a Language 49
Closing the SmartSYNC Window 50
Quitting SmartSYNC 50
Displaying the EdgeStores on your Network 50
Starting EASM 50
Connecting a Network Drive 52
Deleting Device (Network Drive) Records 53
Performing a Backup 53
Viewing Your Backup Folders 54
Performing a Restore 55
Scheduling a Backup 56
Modifying a Backup Schedule 57
Deleting a Backup Schedule 57
Setting the Default Browser for EASM 58
Viewing the Event Log 58
Clearing the Event Log 58
Saving the Event Log to a Text File 58

Chapter 6: EASM 59
Connecting to EASM 59
EASM in your Browser 60
EASM in SmartSYNC 61
Choosing a Language 62
Navigating in EASM 62
Setting up EdgeStore with the Setup Wizard 63
Managing Users and Groups 65
Viewing a List of Users 65
Creating a User 65
Changing the Administrator’s Password 65
Changing a User's Password 66
Deleting a User 66
Viewing a List of Groups 66

Chapter 6: EASM, cont.

Managing Users and Groups, cont.
- Creating a Group 67
- Adding Members to a Group 67
- Removing Members from a Group 67
- Deleting a Group 68
- Viewing Quotas 68
- Setting Quotas 68

Managing File & Print Services 70
- Setting up Windows Access 70
- Setting up UNIX/Linux Access 71
- Setting up for Macintosh Access 72
- Setting up for FTP Access 73
- Setting up your Print Server 74
- Setting up your DLNA Server 74
- Viewing a List of Folders 75
- Modifying Folder Services 75
- Adding a Folder 76
- Deleting a Folder 76
- Setting up Windows Sharing for a Folder 77
- Setting up UNIX and Linux Sharing for a Folder 77
- Setting up FTP Sharing for a Folder 78

Managing RAID Volumes 79
- Viewing RAID Volume Status 79
- Viewing Disk Drive Information 80
- Creating a RAID Volume 80
- Designating a Spare Drive 81
- Migrating a RAID Volume 81
- Deleting a RAID Volume 82
- Viewing an External USB Drive or Memory Stick 83
- Formatting an External USB Drive or Memory Stick 83

Managing Backups 84
- Viewing a List of Snapshot Backups 84
- Setting up a Snapshot Backup 84
- Scheduling a Snapshot Backup 85
- Recovering Snapshot Backups 85
- Viewing the NAS Replication Schedule 86
- Setting up NAS Replication 86
- Enabling One Touch Backup 87

Chapter 6: EASM, cont.
Managing the Network Connection 88
Viewing Network Setup Information 88
Making Network Settings 88
Working with Jumbo Frames 89
Setting up your DDNS Service 90
Making Management Settings 91
Viewing Service Status 91
Viewing the Event Log 92
Setting up SMTP Authentication 92
Viewing the Email Alert List 93
Adding an Email Alert Recipient 93
Deleting an Email Alert Recipient 93
Upgrading the System Firmware 93
Installing an Application Plug-in 93
Enabling and Disabling the Buzzer 94
Viewing UPS Status 94
Setting up a UPS 95
Managing Services 96
Setting System Date and Time 96
Running the Network Time Protocol 96
Viewing the Results of NTP Synchronization 97
Rebooting the EdgeStore 97
Shutting Down the EdgeStore 98
Restarting the EdgeStore 98
Locating the EdgeStore 98
Viewing System Information 99
Viewing Enclosure Information 99

Chapter 7: Technology Background 101
Introduction to RAID 101
RAID 0 – Stripe 102
RAID 1 – Mirror 103
RAID 5 – Block Striping with Distributed Parity 104
RAID 10 – Mirror / Stripe 105
Choosing a RAID Level 106
RAID 0 106
RAID 1 106
RAID 5 107
RAID 10 107

Chapter 7: Technology Background, cont.
Spare Drive 107
Automatic Rebuilding 108
Partition and Format 108
RAID Volume Migration 109
RAID 0 109
RAID 1 109
RAID 5 110
RAID 10 110

Chapter 8: Troubleshooting 111
Responding to an Audible Alarm 111
Checking the System Status LED 112
Checking Disk Status LEDs 112
Replacing a Failed Disk Drive 113
Checking RAID Volume Status in EASM 113
EdgeStore Responds to a Critical RAID Volume 114
Responding to an Invalid RAID Volume 114
Checking File System Status in EASM 115
Rebuilding the File System 116
Checking the Event Log in EASM 116
Responding to Events 117
Checking Enclosure Status in EASM 120
Resolving Connections with SmartSYNC 121
Multiple Network Connections 122
Solving Network Connection Problems 123
Checking Your Email Inbox 124
Restoring the Default Password 124
Resolving a Windows Firewall Issue 125

Chapter 9: Support 127
Frequently Asked Questions 127
Contacting Technical Support 130
Limited Warranty 131
Returning Product For Repair 133

Appendix A: SmartWizard Advanced Mode 135

Appendix B: Maintenance 143
Upgrading the Firmware 143
Rebooting the EdgeStore 144
Installing Application Plug-ins 145
Connection Problems After Restart 146

Appendix C: GNU General Public License 147

Index. 149

Chapter 1: Introduction to EdgeStore

- About This Manual (page 1)
- Architecture (page 2)
- Protocol Support (page 2)
- Key Benefits (page 2)
- Specifications (page 3)
- Compatible Backup Software (page 4)
- Client OS Support (page 4)
- Browser Support (page 4)

Edge10's EdgeStore NAS400 is a network attached storage (NAS) solution for external storage targeted for small and medium business (SMB) users and small office/home office (SOHO) users.

With a NAS product, users can save their work and have access to files over the network without having to carry around a disk drive or memory stick. The Administrator can manage access privileges for greater security. Multiple backup and synchronization functions protect your data.

About This Manual

This *Product Manual* describes how to setup, use, and maintain the EdgeStore NAS400. It also describes how to use the NAS Setup Wizard, SmartSYNC utility, and Edge10 Advanced Storage Manager (EASM) software.

This manual includes a full table of contents, chapter task lists, and numerous cross-references to help you find the specific information you are looking for.

Also included are four levels of notices:

Note

A *Note* provides helpful information such as hints or alternative ways of doing a task.

Important

An *Important* calls attention to an essential step or point required to complete a task. Important items include things often missed.

Caution

A *Caution* informs you of possible equipment damage or loss of data and how to avoid them.

Warning

A *Warning* notifies you of probable equipment damage or loss of data, or the possibility of physical injury, and how to avoid them.

Architecture

The EdgeStore NAS400's architecture is based on the Freescale MPC8343 microprocessor and the Promise PDC40719 Serial ATA RAID Controller. The Gigabit Ethernet port is used for the data transfer and management. The USB ports are used for a printer, expansion drives, and Uninterruptable Power Supply (UPS).

Protocol Support

EdgeStore NAS400 supports:

- Windows 2000, XP Professional, 2003 Server; and Vista Business, Enterprise, and Ultimate clients through SMB and CIFS protocols
- UNIX and Linux clients through the NFS protocol
- Macintosh clients through the AFP protocol
- FTP clients through the FTP protocol
- DLNA clients through UPnP protocol with an optional plug-in
- Up to 16 concurrent connections

Key Benefits

- Easy-to-use browser-based management interface
- Data sharing over the network
- One-touch backup of designated file folders on client PC
- Snapshot backup for real-time image of the file system
- Remote NAS-to-NAS synchronization and backup
- Network print server with USB printer
- User, Group, and Quota management
- UPS support with automated shutdown
- Heterogeneous environment: Windows, UNIX, Linux, and Macintosh

- SmartSYNC Backup Utility
- Setup Wizard Utility

Specifications

- Disk drive support:
  - Four 1.5 Gb/s or 3 Gb/s SATA 3.5-inch disk drives
  - Conforms to Serial ATA 1.0 specification and Serial ATA II: Extensions to Serial ATA 1.0 specification (SATA II, phase I specification)
  - SATA specification of 3 Gb/s transfers with CRC error-checking
  - Hot-swapping of disk drives
  - Tagged command queuing
  - Native command queuing
  - Drive roaming among channels
  - S.M.A.R.T. status polled every 15 minutes
  - Online capacity expansion
  - RAID Level Migration
  - Hot spare drives
  - RAID Volume rebuilding
  - Gigabyte rounding
  - Background rebuilding
- RAID level support: RAID 0, 1, 5, and 10
- Large file system support up to 4 TB
- Unicode file name support
- SATA RAID Controller: Promise PDC40719
- Server on a Chip: Freescale MPC8343, 400MHz
- Networking: 10/100/1000 Mb/s Ethernet Port on motherboard
- USB ports: USB 2.0, up to 480 Mb/s, two Type-A connectors
- File protocols: SMB, CIFS, FTP, AFP, NFS
- Flash Memory: 16 MB, 16-bit
- Memory: 128 MB DDR SDRAM
- Power Supply: 200-watt ATX with PFC
- Network Time Protocol (NTP) client
- Error logging
- Phone home capability (email notification) to contact IT staff

- Hardware monitoring of:
  - Fan
  - Temperature
  - Power
  - Disk status
  - One-Touch button
  - Enclosure status

Compatible Backup Software

EdgeStore NAS400 is compatible with the following backup software products:

- VERITAS® NetBackup/Backup Exec™
- CA BrightStor™ARCserve/Enterprise
- LEGATO® NetWorker™
- Syncsort Backup Express
- Microsoft Backup Software for Windows 95/98/NT/2000/ME/XP
- Dantz Retrospect for Macintosh

Client OS Support

Microsoft Windows:

- Vista Business, Enterprise, and Ultimate; Server 2003, XP Professional, 2000
- Supports Intel IA32, AMD64 and Intel EM64T platforms

UNIX/Linux:

- Red Hat Enterprise Linux 3.0 (AS/WS/ES)
- Red Hat Enterprise Linux 4.0 (AS/WS/ES)
- SuSe Linux Enterprise 10 (Server/Desktop)

Apple Macintosh:

- MacOS X

Browser Support

Use the latest version of the following browsers to manage the EdgeStore NAS400:

- Internet Explorer
- Netscape Navigator
- Mozilla
- Firefox
- Safari (MacOS X)

Chapter 2: Installation and Setup

- Unpacking the EdgeStore NAS400 (page 5)
- Installing Disk Drives (page 7)
- Connecting to the Network (page 7)
- Connecting the Power (page 8)
- Installing the Software (page 8)
- Optional. Selecting Your Network (page 12)
- Setting up the EdgeStore (page 13)
- Connecting to EASM (page 17)
- Shutting Down the EdgeStore (page 20)

Unpacking the EdgeStore NAS400

The EdgeStore NAS400 box contains the following items:

- EdgeStore NAS400 Unit
- *Quick Start Guide*
- Screws for disk drives (16, including 4 spares)
- Ethernet cable
- 1.5m (4.9 ft) Power cord
- CD with NAS Setup Wizard, SmartSYNC software, and Configuration Tool, *Product Manual* and *Quick Start Guide*

Warning

The electronic components within the EdgeStore are sensitive to damage from Electro-Static Discharge (ESD). Observe appropriate precautions at all times when handling the EdgeStore or its subassemblies.

Important

To configure the EdgeStore, you must install the software onto a PC running Windows Vista Business, Enterprise or Ultimate; 2003 Server, XP Professional, or 2000.

Figure 1. EdgeStore NAS400 Front View



Note: This EdgeStore is shown without the front door.

Figure 2. EdgeStore NAS400 Rear View



Installing Disk Drives

You can populate the EdgeStore NAS400 with SATA 1.5 Gb/s or 3.0 Gb/s disk drives. For optimal performance, install disk drives of the same model and capacity. Your disk drives will become a RAID Volume on the EdgeStore.

To install disk drives:

1. Open the door on the front of the EdgeStore enclosure.
2. Pull a disk drive carrier from the enclosure. See Figure 1.
3. Carefully lay the disk drive into the drive carrier, so that the screw holes on the sides of the carrier align with the screw holes in the drive.
4. Insert the screws through the holes in the drive carrier and into the sides of the disk drive.
   - Install only the counter-sink screws supplied with the EdgeStore.
   - Install four screws per drive.
   - Snug each screw. Be careful not to over-tighten.
5. Reinstall the drive carrier into the EdgeStore enclosure.

   Repeat steps 2 through 5 until all of your disk drives are installed.
6. Close the door on the front of the EdgeStore.

Connecting to the Network

To connect the EdgeStore to your network:

1. Attach one end of the network cable to the RJ45 network connection. See Figure 2.
2. Attach the other end of the network cable to your Ethernet hub or switch.

Important

If there are multiple networks at your facility, note the network to which you connect the EdgeStore. You will need this information during the setup process.

Connecting the Power

To power the EdgeStore:

1. Attach the power cord on the back of the EdgeStore enclosure and plug the other end into the power source. See Figure 2.
2. On the front of the EdgeStore, press the power button. See Figure 1.

   It takes about a minute to boot the EdgeStore. When fully booted:

   - The System Status LED turns green. See Figure 1.
   - The buzzer beeps one time.

Installing the Software

When you install the software onto your Windows PC, three new items are added to the Windows Start menu:

- **SmartWizard** – Sets up the EdgeStore
- **SmartSYNC** – Connects your PC to the EdgeStore, sets up network drives on your PC, and performs backups
- **Configure Tool** – Ensures that the EdgeStore, SmartWizard, and SmartSYNC are all on the same network

To install the software:

1. Insert the CD into your CDROM.
2. Double-click the **NAS Utility Installer** icon.

   The Choose Setup Language dialog box appears.



3. Choose your setup language from the dropdown menu.

   Click the **OK** button.

The first installer screen appears.


Edge10 NAS Utility - InstallShield Wizard
Welcome to the InstallShield Wizard for Edge10 NAS Utility
The InstallShield(R) Wizard will install Edge10 NAS Utility on your computer. To continue, click Next.
WARNING: This program is protected by copyright law and international treaties.
< Back
Next >
Cancel

4. Click the **Next** button to begin installation.
   The License Agreement screen appears.


Edge10 NAS Utility - InstallShield Wizard
License Agreement
Please read the following license agreement carefully.
To add your own license text to this dialog, specify your license agreement file in the Dialog editor.
1. Navigate to the User Interface view.
2. Select the LicenseAgreement dialog.
3. Choose to edit the dialog layout.
4. Once in the Dialog editor, select the Memo ScrollableText control.
5. Set FileName to the name of your license agreement RTF file.
After you build your release, your license text will be displayed in the License Agreement dialog.
I accept the terms in the license agreement
I do not accept the terms in the license agreement
Print
InstallShield
< Back
Next >
Cancel

5. Click the “I accept the terms...” option, then click the **Next** button.

The Customer Information screen appears.



6. Type a user name and organization name into the respective fields or leave them unchanged to accept the default entries.

   Click the Install option for:

   - Anyone who uses this computer (all users)
   - Only for me (the current user)

   Click the **Next** button.

The Ready to Install screen appears.


Edge10 NAS Utility - InstallShield Wizard
Ready to Install the Program
The wizard is ready to begin installation.
Click Install to begin the installation.
If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.
InstallShield
< Back
Install
Cancel

7. Click the **Install** button to proceed with installation.
   When the installation is finished, the final installation screen appears.


Edge10 NAS Utility - InstallShield Wizard
InstallShield Wizard Completed
The InstallShield Wizard has successfully installed Edge10 NAS Utility. Click Finish to exit the wizard.
< Back
Finish
Cancel

8. Click to **Finish** button to close the installer.

Optional. Selecting Your Network

If your PC has only one network connection, skip to “Setting up the EdgeStore” on page 13.

If your PC has multiple network connections, you must ensure that the EdgeStore, NAS Setup Wizard, and SmartSYNC utility are all connected to the same network. The Configuration Tool performs that function.

To make your network selection:

1. From the Windows Start menu, choose *Programs*, then *Edge10 NAS Utility*, and then *Configuration Tool*.

   The Change system configuration screen appears.



2. From the Language dropdown menu, choose the language you prefer.
3. From the Scan Network Interface dropdown menu, choose the IP address for the network where you installed the EdgeStore.

   The IP addresses in this menu belong to the network interface cards (NICs) in your PC. You must select the NIC that is connected to the network where you installed the EdgeStore.
4. Optional. Click the **...** button to navigate to the browser you want to use as with the EdgeStore.

   The default browser appears in the Browser Path field. Change this setting only if you want use a different browser.
5. Click the **OK** button.
6. In the System Message, click **OK** to finish your network selection.

Setting up the EdgeStore

Caution

The SmartWizard will overwrite all existing settings on the EdgeStore. In most cases, you should only run the SmartWizard one time—when you first set up your EdgeStore.

The SmartWizard performs the setup procedures on your EdgeStore.

To set up your EdgeStore:

1. From the Windows Start menu, choose *Programs*, then *Edge10 NAS Utility*, then *SmartWizard*.

   The SmartWizard welcome screen appears.

2. From the Choosing a language dropdown menu, choose the language you prefer.
3. Choose an Initiation Mode.

   Click the *Express Mode* option if ALL of these conditions apply:

   - You have a DHCP server on your network with addresses available.
   - You want data protection for your RAID Volume.
   - You want to use date and time settings from your PC.

Click the *Advanced Mode* option if one or more of these conditions apply:

- You do not have a DHCP server on your network.
- You have a DHCP server but no addresses are available.
- You want to set the IP address manually.
- You want maximum capacity RAID 0 Volume.
- You want to set date and time manually.

The rest of the setup instructions describe Express mode. For setup instructions using Advanced mode, see “Appendix A: SmartWizard Advanced Mode” on page 135.

4. Click **Next >>** to continue.

   The Discovering Edge10 NAS screen appears. The EdgeStore is listed as a *NAS400*.



5. Highlight the EdgeStore you are initiating, then click **Next >>** to continue.

The Login dialog box appears.



6. Type **admin** into the Password field, then click **OK**.

   The password is case sensitive.

   The Select a Device Name screen appears.


Smart Wizard
Assigning a network device name.
The Wizard has created a shared folder "PUBLIC" for you.
Please enter a Device Name for the shared folder.
Device Name :
Z:
Click NEXT to continue.
<< BACK
NEXT >>
CANCEL

7. Select a Device Name (drive letter) to represent the default folder on the EdgeStore as a network drive on your PC.

   The list begins with Z and goes in reverse alphabetical order.

   Click **Next >>** to continue.

The System Message appears.



8. Click the **Yes** button to begin the system initiation.

   The Wizard requires several minutes to configure your EdgeStore, depending on the size of your disk drives. When the Wizard is done another System Message appears.



9. Click **OK** to finish the system initiation.

   The Wizard creates a RAID Volume and a default folder called *Public*.

   If two disk drives are installed in your EdgeStore, the Wizard creates a RAID 1 Volume. If three or four disk drives are installed, the Wizard creates a RAID 5 Volume.

   The Public folder on the EdgeStore appears under My Computer as a network drive.


My Computer
File Edit View Favorites Tools Help
Back Search Folders
Address My Computer
Name Type Total Size Free Space Commen
Hard Disk Drives
Local Disk (C:) Local Disk 37.2 GB 30.5 GB
Devices with Removable Storage
3½ Floppy (A:) 3½-Inch Floppy Disk
CD Drive (D:) CD Drive
Network Drives
public on 'NAS400 (192.168.1.110)' (Z:) Network Drive 455 GB 297 GB

You can now copy files to and from the folder on the EdgeStore.

Connecting to EASM

The Edge10 Advanced Storage Manager (EASM) software is factory-installed on the EdgeStore system. EASM runs in the browser on your PC. You can access EASM:

- Directly in your browser. See page 18.
- Through SmartSYNC. See page 19.

Browser Support

Choose one of the following browsers to use with EASM:

- Internet Explorer
- Mozilla
- Firefox
- Netscape Navigator
- Safari (MacOS X)

Finding the EdgeStore's IP Address

To access the EdgeStore in your browser, you must know the EdgeStore's IP address. Use SmartSYNC for this purpose.

1. From the Windows Start menu, choose *Programs*, then *Edge10 NAS Utility*, and then *SmartSYNC*.
2. To open the SmartSYNC window, in the Windows application tray (lower right corner of the screen), double-click the **SmartSYNC** icon.

   The SmartSYNC screen appears with the Server Information tab displayed. The IP address of the EdgeStore shown in the Server List.





EASM in your Browser

To log into EASM in your browser:

1. Start your Browser.
2. In the Browser address field, type in the IP address of the EdgeStore.

   See “Finding the EdgeStore’s IP Address” on page 17.

   Note that the IP address shown below is only an example. The IP address you type into your browser will be different.

   - EASM uses an HTTP connection . . . . . .http://
   - Enter the EdgeStore’s IP address 192.168.1.110

   Together, your entry looks like this: **http://192.168.1.110**

   The EASM login screen displays.

3. Type the user name and password in the respective fields, then click the **Login** button.

   The default user name is **admin**. The default password is **admin**.

   The user name and password are case sensitive.

   For more information about EASM, see “Chapter 6: EASM” on page 59.

EASM in SmartSYNC

To log into EASM in SmartSYNC:

1. In the Windows application tray (lower right corner of the screen), double-click the **SmartSYNC** icon (right).

   SmartSYNC opens with the Server Information tab displayed.

2. Click the **Open GUI** button (right).

   Your default browser starts and the EASM login screen displays.

3. Type the user name and password in the respective fields, then click the **Login** button.

   The default user name is **admin**. The default password is **admin**.

   The user name and password are case sensitive.

   For more information about EASM, see “Chapter 6: EASM” on page 59.

Shutting Down the EdgeStore

To shut down the EdgeStore, press and hold the power button for five seconds. See Figure 3. The system status LED turns red, then goes dark.

To restart the EdgeStore, press the power button again.

Figure 3. Press and hold the Power button for 5 seconds



Note: This EdgeStore is shown without the front door.

Chapter 3: Connecting to the EdgeStore

- Setting up a Network Drive on a Windows PC (page 21)
- Setting up a Network Drive on a UNIX or Linux PC (page 24)
- Setting up a Network Drive on a Macintosh PC (page 27)
- Connecting a USB Printer to EdgeStore (page 31)
- Setting up the Print Server on EdgeStore (page 32)
- Setting up Windows Printing (page 32)
- Setting up Linux Printing (page 34)
- Setting up Macintosh Printing (page 37)
- Connecting a USB Drive (page 39)
- Disconnecting a USB Drive (page 42)

To copy files to and from a folder on the EdgeStore, you must make the folder a network drive on your PC.

To use the EdgeStore as a print server, you must connect the USB printer, enable EdgeStore's print server, and set up printing on your PC.

Setting up a Network Drive on a Windows PC

You can also use SmartSYNC for this purpose, see "Connecting a Network Drive" on page 52. If your PC does not have SmartSYNC, use the following procedure to setup a Network Drive with My Network Places.

To setup a network drive:

1. On the Windows desktop, double-click the **My Network Places** icon.
2. Click the **Search** button in the toolbar.



If the Search button is not shown, from the View menu, choose *Toolbars*, then *Standard Buttons*.

3. In the Computer name field, type the IP address of the EdgeStore and click the **Search** button.

See “Finding the EdgeStore’s IP Address” on page 17.



The EdgeStore appears in the search results list.



4. Double-click the **EdgeStore** to show the Public folder and any other folders you have created.

5. Right-click the folder you want and choose *Map Network Drive* from the dropdown menu.



The Map Network Drive dialog box appears.


Map Network Drive
Windows can help you connect to a shared network folder and assign a drive letter to the connection so that you can access the folder using My Computer.
Specify the drive letter for the connection and the folder that you want to connect to:
Drive: Z:
Folder: \\192.168.1.110\public
Browse...
Example: \\server\share
Reconnect at logon
Connect using a different user name.
Sign up for online storage or connect to a network server.
< Back
Finish
Cancel

6. In the Map Network Drive dialog box, choose a drive letter and click the **Finish** button.
7. Double-click the **My Computer** icon on your Windows desktop.

The folder on the EdgeStore appears under My Computer as a network drive.


My Computer
File Edit View Favorites Tools Help
Back Search Folders
Address My Computer
Name Type Total Size Free Space
Hard Disk Drives
Local Disk (C:) Local Disk 37.2 GB 30.5 GB
Devices with Removable Storage
3½ Floppy (A:)
CD Drive (D:)
Network Drives
public on 'NAS400 (192.168.1.110)' (Z:) Network Drive 455 GB 297 GB
EdgeStore (NAS400) under Network Drives

You can now copy files to and from the folder on the EdgeStore.

Setting up a Network Drive on a UNIX or Linux PC

Before you can access the EdgeStore from a UNIX or Linux PC, you must configure the EdgeStore to communicate with UNIX and Linux.

On the Windows PC

1. Start EASM.

   See “EASM in your Browser” on page 18 or “EASM in SmartSYNC” on page 19.

2. In the Tree, click the **+** beside the **File & Print** icon to expand the Tree.
3. Click the **Protocol Control** icon, then click the **UNIX/Linux** tab.



4. Next to Service, click the **Enable** option, then click the **OK** button.

The UNIX/Linux protocol enables UNIX and Linux PCs to connect to EdgeStore.

5. Click the **File Sharing** icon in the tree.
6. Click the **Modify** tab.



7. Check the **Unix/Linux** box, then click the **OK** button.

   The UNIX/Linux file sharing enables UNIX and Linux PCs to access folders on the EdgeStore. In this case, access is given for the PUBLIC folder.
8. Click the **Sharing Setup** icon in the tree.
9. Click the **UNIX/Linux Sharing** tab.



10. In the New IP Address field, type the IP address of the UNIX/Linux PC from which you want to access the EdgeStore.
11. Click the **Add** button.

On the UNIX/Linux PC with Command Line Interface

1. Open a terminal window.
2. Create a new folder for the EdgeStore. Type **mkdir EdgeStore** and press Enter.
3. Mount the EdgeStore. Type **mount 192.168.1.110:/VOLUME1/PUBLIC/ EdgeStore** and press Enter.

   Note that the IP address shown above is only an example. The IP address you type in your terminal window will be different.

   “Finding the EdgeStore’s IP Address” on page 17.

   Volume1 and Public refer to the default Volume and folder created during setup.See page 13. If you created another volume or folder, use their names.
4. Change to the EdgeStore directory. Type **cd /EdgeStore** and press Enter.

   You can now copy files to and from the folder on the EdgeStore.
5. When you are done with the EdgeStore, type **cd; umount /EdgeStore** and press Enter.

On the Linux PC with Graphic Desktop

This procedure is for a RedHat Enterprise Linux 4 configuration. If you run a different version of Linux, you might have to adapt the procedure. See your OS documentation.

1. From the Applications menu, choose *Network Servers*.
2. In the Network window, double-click Windows Network.

   Note that the EdgeStore (NAS400) is identified by its server name.
3. Double-click the EdgeStore icon.



4. Double-click the folder you want.

   If this is the first time you accessed this folder, an Authentication dialog box opens.



5. Type the user name and password in the respective fields, then click the **OK** button.

   The default user name is **admin**. The default password is **admin**.

   The user name and password are case sensitive.

   Leave the Domain field blank.

   The folder opens. You can now copy files to and from the folder on the EdgeStore.

Setting up a Network Drive on a Macintosh PC

Before you can access the EdgeStore from a Macintosh (MacOS X) PC, you must configure the EdgeStore to communicate with the MacOS.

On the Windows PC

1. Start EASM.

   See “EASM in your Browser” on page 18 or “EASM in SmartSYNC” on page 19.

2. In the Tree, click the **+** beside the **File & Print** icon to expand the Tree.
3. Click the **Protocol Control** icon, then click the **Macintosh** tab.



4. Next to Service, click the **Enable** option, then click the **OK** button.
   The Macintosh protocol enables Macintosh PCs to connect to EdgeStore.
5. Click the **File Sharing** icon in the Tree.
6. Click the **Modify** tab.



7. Check the **Macintosh** box, then click the **OK** button.
   The Macintosh file sharing enables Macintosh PCs to access folders on the EdgeStore. In this case, access is given for the PUBLIC folder.

On the Macintosh PC

1. From the Go menu, choose *Connect to Server*.



2. In the Connect to Server dialog box, type **afp://192.168.1.110** and click the **Connect** button.

   Note that the IP address shown below is only an example. The IP address you type in the dialog box on your Macintosh will be different.

   See “Finding the EdgeStore’s IP Address” on page 17.

   Click the **+** button to add this IP address to the Favorite Servers list.



3. Type the user name and password in the respective fields, then click the **OK** button.

   The default user name is **admin**. The default password is **admin**.

   The user name and password are case sensitive.

Note that the EdgeStore (NAS400) is identified by its server name.



4. In the Select the volumes dialog box, click the folder you want, then click the **OK** button.



5. In the Welcome screen, click the **OK** button.

A window opens on the Macintosh desktop to access the folder on the EdgeStore.

You can now copy files to and from the folder on the EdgeStore.

Connecting a USB Printer to EdgeStore

To connect a USB printer to the EdgeStore:

1. Set up your printer according to the printer's *Setup Guide* or *User Manual*.
2. Install the printer drivers onto your PC as described in the printer's *Setup Guide* or *User Manual*.
3. Attach the USB cable from your printer to one of the USB connections on the back of the EdgeStore.



Setting up the Print Server on EdgeStore

To set up the EdgeStore's print server:

1. Start EASM.

   See "EASM in your Browser" on page 18 or "EASM in SmartSYNC" on page 19.
2. In the Tree, on the left side of the EASM screen, click the **+** beside the **File & Print** icon to expand the Tree.
3. Click the **Protocol Control** icon, then click the **Windows** tab.
4. Click the **Enable** option button beside Services.
5. Click the **OK** button to save your settings.
6. Click the **Printer Server** tab.
7. Click the **Enable** option button beside Printer Server.
8. Click the **OK** button to save your settings.



Setting up Windows Printing

To set up printing on a Windows PC:

1. On the Windows desktop, double-click the **My Network Places** icon.
2. Click the **Search** button in the toolbar.

   If the Search button is not shown, from the View menu, choose *Toolbars*, then *Standard Buttons*.
3. In the Computer name field, type the IP address of the EdgeStore and click the **Search** button in the side bar.

   See "Finding the EdgeStore's IP Address" on page 17.

   The EdgeStore appears in the search results list.
4. In the computer list, double-click the **EdgeStore** to open it.

If the Connect to dialog box appears, type the user name and password in the respective fields, then click the **OK** button.

The default user name is **admin**. The default password is **admin**.

The user name and password are case sensitive.



5. Right-click the **usbptr1** icon folder and choose *Connect...* from the dropdown menu.



6. When the warning message about printer drivers appears, click the **OK** button to continue.

7. In the Add Printer Wizard, click the Manufacturer and model name of your USB printer, then click the **OK** button.



8. In the Add Printer Wizard, click the **OK** button.
9. To verify printer installation, in the Windows Start menu, choose *Settings*, then *Printers and Faxes*.

   The Printers and Faxes screen appears. The **usbptr1** is the USB printer on the EdgeStore.



Setting up Linux Printing

This procedure is for a RedHat Enterprise Linux 4 configuration. If you run a different version of Linux, you might have to adapt the procedure. See your OS documentation.

1. From the Applications menu, choose *System Settings*, then *Printing*.

   Printer configuration window opens.
2. Click the **New** button.

   Add a new print queue dialog box opens.

3. Click the **Forward** button.
4. In the Name field, type a name for the printer, such as *NAS_printer*, a description, and click the **Forward** button.


Add a new print queue
Queue name
Please enter a name for this queue. Choose a short name that begins with a letter and contains no spaces.
Name: NAS_Printer
About
If you like, you can enter a description of the printer to help you identify it more easily.
Short description: NAS400 USB printer
Help
Cancel
Back
Forward

5. From the Select a queue type dropdown menu, choose *Network Windows (SMB)*.
6. Scroll the list and click the **triangle** icon beside EdgeStore.

   Note that the EdgeStore (NAS400) is identified by its server name.

   USBPTR01 appears below the EdgeStore and represents the USB printer connected to the EdgeStore.



7. Highlight *USBPTR01* and click the **Forward** button.

   The Authentication dialog box opens.

In the User name and Password fields, type **admin**, then click the **OK** button.

The user name and password are case sensitive.



The Printer Model dialog box opens.

8. From the dropdown menu, choose the manufacturer of your printer.

   From the model list, highlight the model of your computer.

   Then click the **Forward** button.



9. Click the **Finish** button.

USBPTR01 is added to your printer list.



Setting up Macintosh Printing

To set up printing on a Macintosh PC:

1. From the Apple Menu, choose *System Preferences*.
2. Double-click the **Print & Fax** icon.
3. Click the **Setup Printers** button.
4. In the Printer List, click the **Add** icon.
   The Printer List displays a new panel.
5. In the new panel, from the popup menus, choose:
   - Windows Printing
   - Workgroup
6. From the list, highlight the EdgeStore, then click the **Choose** button.
   Note that the EdgeStore is listed by its server name.



A user name and password dialog box appears.

7. Type the user name and password in the respective fields, then click the **OK** button.

   The default user name is **admin**. The default password is **admin**.

   The user name and password are case sensitive.



   The printer list displays a new panel.

8. Highlight the *USBPTR01* in the list.

   USBPRT01 represents the USB printer connected to the EdgeStore.



9. In the Printer Model popup menu, choose the make of your printer.
10. In the Model Name list, choose the model of your printer.

11. Click the **Add** button.

    USBPTR01 is added to your printer list.



Connecting a USB Drive

To connect a USB drive to the EdgeStore, attach the USB cable from your external drive to one of the USB connections on the back of the EdgeStore.

If you have a USB memory stick, attach it directly to one of the USB connections or use a USB cable, whichever is more convenient.



The USB drive or memory stick appears as a folder called *usbdisk* when you create your network drive. See the instructions on the following page.

EdgeStore supports USB drives and memory sticks formatted to FAT32 and Ext3 file formats. If the EdgeStore does recognize the USB drive or memory stick, the

usbdisk folder does not appear. See “Formatting an External USB Drive or Memory Stick” on page 83.

Windows PC

The USB drive appears as a folder on the EdgeStore when you create a network drive on a Windows PC.



Follow the procedure “Setting up a Network Drive on a Windows PC” on page 21, but choose the *usbdisk* folder instead of the *public* folder.

Linux PC

The USB drive appears as a folder on the EdgeStore when you create a network drive on a Linux PC.



Follow the procedure “Setting up a Network Drive on a UNIX or Linux PC” on page 24, but choose the USBDISK folder instead of the PUBLIC folder.

Macintosh PC

The USB drive appears as a folder on the EdgeStore when you create a network drive on a Macintosh PC.



Follow the procedure “Setting up a Network Drive on a Macintosh PC” on page 27, but choose the USBDISK folder instead of the PUBLIC folder.

Disconnecting a USB Drive

To disconnect a USB drive or memory stick from the EdgeStore:

1. Be sure that no files on the USB drive or memory stick are still open.
2. Unplug the USB drive or memory stick from the EdgeStore.
   The EdgeStore automatically unmounts the USB drive or memory stick.

Chapter 4: One Touch Backup

- Enabling One Touch Backup (page 43)
- Creating a Backup Schedule (page 44)
- Performing a One Touch Backup (page 45)
- Viewing Your Backup Files (page 46)
- Restoring Your Backup Files (page 47)

One Touch Backup enables you to make a quick, automated backup of a selected folder on your PC, at the touch of a button. You can backup the files in a single folder, multiple folders, or your complete hard disk drive. This feature works on the Windows PC where you installed the EdgeStore software.

Caution

The EdgeStore and One Touch Backup cannot restore a failed boot drive in your PC. However, you can use the EdgeStore to save your system backup file. See your Windows documentation for information about system backups.

For One Touch Backup to work, you must:

- Enable One Touch Backup on the EdgeStore
- Create a Backup Schedule in SmartSYNC

Notes

- Windows does not allow SmartSYNC to access protected folders and files. If you want to perform a backup, you must first disable protection on your folders and files.
- If you want to run the Windows Backup or Restore Wizard, access the EdgeStore as a network drive. See “Setting up a Network Drive on a Windows PC” on page 21.

Enabling One Touch Backup

To enable One Touch Backup on the EdgeStore:

1. On the Windows PC, start EASM.

   See “EASM in your Browser” on page 18 or “EASM in SmartSYNC” on page 19.

2. In the Tree, click the **+** beside the Backup icon, then click the Client Backup icon.

3. On the **One Touch Backup** tab, click the **Enable** button for One Touch Backup Services, then click the **OK** button.

Creating a Backup Schedule

For each folder you want to backup, you must create a backup schedule.

To create a Backup Schedule in SmartSYNC:



1. On the Windows desktop, double-click the SmartSYNC icon (right).
2. In SmartSYNC, click the **Schedule** tab.
3. Click the **Create** button.
4. In the Backup Schedule window, verify the Destination.

   The destination is a letter, typically Z, Y, or X, which represents a network drive on your PC and a specific folder on the EdgeStore.
5. In the folder list, click the **+** icons to expand the tree.

   The Folder List is a representation of the file structure on your PC.



6. Click the folder you want to backup.

   A checkmark appears beside the selected folder. The backup will include the folder you select and all subfolders.
7. Click the **Next >>** button.
8. Choose a Schedule interval by number of hours, daily, or weekly.
9. Choose a setting:
   - If you chose hours, choose the number of hours from the dropdown menu.

- If you chose daily, choose the time of day in the hour (24-hour clock) and minutes dropdown menu.
- If you chose weekly, choose the time of day and day of the week in the hour (24-hour clock), minutes, and day dropdown menus.



10. Click the **Finish** button.

    Your Backup Schedule appears in the **Schedule** tab.

Performing a One Touch Backup

To perform a One Touch Backup, press the **One Touch Backup** button on the front of the EdgeStore.



Within moments, the folders you specified are backed up onto the EdgeStore. The One Touch Backup function backs up all of the folders on your PC for which you created a backup schedule.

Viewing Your Backup Files

To view your backup files on the EdgeStore:

1. On the Windows PC desktop, double-click the My Computer icon.
2. Under Network Drives, double-click the EdgeStore.


My Computer
File Edit View Favorites Tools Help
Back Search Folders
Address My Computer
Name Type Total Size Free Space Commen
Hard Disk Drives
Local Disk (C:) Local Disk 37.2 GB 30.5 GB
Devices with Removable Storage
3½ Floppy (A:) 3½-Inch Floppy Disk
CD Drive (D:) CD Drive
Network Drives
public on 'NAS400 (192.168.1.110)' (Z:) Network Drive 455 GB 297 GB

3. On the EdgeStore, find the BACKUP folder.

   The BACKUP folder contains the results of the One Touch Backup from your PC. The subfolders inside the BACKUP folder match the file structure on your PC's hard disk drive.

Note

The BACKUP folder takes its name from your account name. For example:

- If your account name is "admin," the folder name is BACKUP_admin.
- If your account name is "Billy," the folder name is BACKUP_Billy.

Restoring Your Backup Files

Caution

The Restore function will overwrite files in the destination folder on your PC.

If the backup files on the EdgeStore match the names of the files in the restore location folder on your PC, the Restore function will overwrite those files on your PC.

If you do not want to overwrite the files on your PC, take one of the following actions:

- Move the current files to a different folder on your PC.
- Choose a different restore location folder.

To restore backup files from the EdgeStore to your PC:

1. On the Windows PC, open SmartSYNC and click the **Restore** tab.
2. In the Source field, choose the folder that contains the backup files that you want to restore.

   In the Source field, folders are identified by their network drive names, such as Z, Y, or X.



3. In the Folder List, click the folders that contain the backup files you want to restore.

In the Folder List, folders are identified by their file structure as it was copied from your PC. The lowest folder in the structure is the one that actually contains the files.



4. Choose a restore location:
   - **Original location** – The same folder on your PC from which the files were copied for the backup.
   - **Select a restore location** – A folder on your PC that you specify.



5. Click the **Start** button.

   The files are copied from the EdgeStore to your PC.

   If you selected a restore location on your PC other than the original, the Restore function includes subfolders that match the files structure on your PC's hard disk drive.

Chapter 5: SmartSYNC

- Opening the SmartSYNC Window (page 49)
- Choosing a Language (page 49)
- Closing the SmartSYNC Window (page 50)
- Quitting SmartSYNC (page 50)
- Displaying the EdgeStores on your Network (page 50)
- Starting EASM (page 50)
- Connecting a Network Drive (page 52)
- Deleting Device (Network Drive) Records (page 53)
- Performing a Backup (page 53)
- Performing a Restore (page 55)
- Scheduling a Backup (page 56)
- Setting the Default Browser for EASM (page 58)
- Viewing the Event Log (page 58)

After installation, the SmartSYNC utility starts automatically in the background on your Windows PC. SmartSYNC does not run on UNIX, Linux, or Macintosh PCs.

Opening the SmartSYNC Window

To open the SmartSYNC window, in the Windows application tray (lower right corner of the screen), double-click the SmartSYNC icon.



The SmartSYNC window opens.

If the SmartSYNC icon does not appear in the Windows application tray, from the Windows Start menu, choose *Programs*, then *Edge10 NAS Utility*, and then *SmartSYNC*.

Choosing a Language

To choose a language, click the Language menu and choose the language you prefer.

Closing the SmartSYNC Window

To close the SmartSYNC window, click the X (close) icon at the top right corner of the window.

The SmartSYNC window closes but the utility continues to run.

To open the SmartSYNC window again, double-click the SmartSYNC icon in the application tray.

Quitting SmartSYNC

To quit SmartSYNC, click the **Exit** button (right).

Exit button

The SmartSYNC utility quits.

To restart SmartSYNC, do one of the following actions:

- Log out of Windows, then log in again.
- From the Windows Start menu, choose *Programs*, then *Edge10 NAS Utility*, and then *SmartSYNC*.

Displaying the EdgeStores on your Network

To display a list of servers (EdgeStores on your network), open the SmartSYNC window.

The SmartSYNC window opens with the Server Information tab selected. A list of servers appears in the Server List on the Server Information tab.

Starting EASM

Edge10 Advanced Storage Manager (EASM) displays in the default browser. To start the default browser and display EASM:

1. Open the SmartSYNC window.
2. Click the **Open GUI** button (right).

Open GUI button

Your default browser starts and the EASM login screen displays.

3. Type the user name and password in the respective fields, then click the **Login** button.

   The default user name is **admin**. The default password is **admin**.

   The user name and password are case sensitive.

   For more information about EASM, see “Chapter 5: SmartSYNC” on page 49.

   Also see “Setting the Default Browser for EASM” on page 58.

Connecting a Network Drive

To access the folders you create on the EdgeStore, you must make them network drives on your PC. See “Adding a Folder” on page 76.

To connect a folder on the EdgeStore as a network drive:

1. Open the SmartSYNC window.
2. Highlight the EdgeStore in the server list, then click the **Connect Network Drive** button (right).

   The Connect Network Drive dialog box appears.

Connect Network Drive button

3. Choose the Device Name and Share Folder from the dropdown menus.

   The Device Name list begins with Z and goes in reverse alphabetical order.

   The Share Folder list represents the folders you have created on the EdgeStore.
4. Click the **OK** button.
5. On the Windows desktop, double-click the My Computer icon.

   The Public folder on the EdgeStore (NAS400) appears under My Computer as a network drive.


My Computer
File Edit View Favorites Tools Help
Back Search Folders
Address My Computer
Name Type Total Size Free Space Commen
Hard Disk Drives
Local Disk (C:) Local Disk 37.2 GB 30.5 GB
Devices with Removable Storage
3½ Floppy (A:) 3½-Inch Floppy Disk
CD Drive (D:) CD Drive
Network Drives
public on 'NAS400 (192.168.1.110)' (Z:) Network Drive 455 GB 297 GB

Deleting Device (Network Drive) Records

To delete a drive record only affects SmartSYNC. Deleting a drive record does NOT delete your network drive under My Computer and it does NOT affect the data stored in your EdgeStore's folders.

To delete a device record:

1. Open the SmartSYNC window.
2. Highlight a server in the Server List.
3. Click the **Remove Device Record** button (right).

   A Device List window appears.

Remove Device Record button

4. Click the Device Name that you want to delete, then click the **Remove** button.

   The Device name is removed from the list.
5. Click X or the **Cancel** button to close the window.

Performing a Backup

A Backup copies folders from your PC to the EdgeStore. Also see "Chapter 4: One Touch Backup" on page 43.

Caution

The EdgeStore and SmartSYNC cannot restore a failed boot drive in your PC. However, you can use the EdgeStore to save your system backup file. See your Windows documentation for information about system backups.

Note

- Windows does not allow SmartSYNC to access protected folders and files. If you want to perform a backup, you must first disable protection on your folders and files.
- If you want to run the Windows Backup or Restore Wizard, access the EdgeStore as a network drive. See "Setting up a Network Drive on a Windows PC" on page 21.

To perform a backup of a selected folder:

1. Open the SmartSYNC window.
2. Highlight a server in the Server List.
3. Click the **Backup** tab.
4. Choose a Destination.

Destinations are identified by drive letters and correspond to a specific folder on the EdgeStore.

5. Click the folder you want to backup in the Folder List.

   Click the **+** icon to expand the file tree.

   A checkmark appears beside the selected folder. The backup will include the folder you choose and all subfolders.

6. Do one of the following actions:
   - To perform the backup now, click **Start** button.
   - To perform the backup later, click the **Apply** button to save your settings.

     When you are ready perform the backup, click the **Backup** button (right).

Backup button

Viewing Your Backup Folders

To view your backup folders on the EdgeStore:

1. On the Windows desktop, double-click the My Computer icon.
2. Under Network Drives, double-click the EdgeStore.
3. On the EdgeStore, find the BACKUP folder.

   The BACKUP folder contains the results of the One Touch Backup from your PC. The subfolders inside the BACKUP folder match the file structure on your PC's hard disk drive.

Note

The BACKUP folder takes its name from your account name. For example:

- If your account name is "admin," the folder name is BACKUP_admin.
- If your account name is "Billy," the folder name is BACKUP_Billy.

Performing a Restore

Caution

The Restore function will overwrite files in the destination folder on your PC.

Note

If you want to run the Windows Backup or Restore Wizard, access the EdgeStore as a network drive. See “Setting up a Network Drive on a Windows PC” on page 21.

A Restore copies folders from the EdgeStore to your PC.

To perform a Restore of a chosen folder:

1. Open the SmartSYNC window.
2. Highlight a server in the Server List.
3. Click the **Restore** tab.
4. Choose a Source.

   Sources are identified by drive letters and correspond to a specific folder on the EdgeStore.
5. Choose a restoration location.
   - **Restore to original location** – The files from the EdgeStore will overwrite the files on our PC
   - **Select a restore location** – The files from the EdgeStore are saved in a set of folders that match the original file structure from where they were copied
6. Optional. If you chose a new Restore location, click the **Browse** button (right), navigate to the destination you want, highlight the destination folder, then click the **Open** button to choose the folder.

Browse button

7. In the Folder List, click the folder you want to restore.

   Click the **+** icon to expand the file tree.

   A checkmark appears beside the chosen folder. The restore will include the folder you chose and all subfolders.
8. Do one of the following actions:
   - To perform the Restore now, click **Start** button.
   - To perform the Restore later, click the **Apply** button to save your settings.

When you are ready perform the backup, click the Tools menu and choose *Restore* > *Start*.

Scheduling a Backup

A Backup copies folders from your PC to the EdgeStore.

Caution

The EdgeStore and SmartSYNC cannot restore a failed boot drive in your PC. However, you can use the EdgeStore to save your system backup file. See your Windows documentation for information about system backups.

Note

- Windows does not allow SmartSYNC to access protected folders and files. If you want to perform a backup, you must first disable protection on your folders and files.
- If you want to run the Windows Backup or Restore Wizard, access the EdgeStore as a network drive. See “Setting up a Network Drive on a Windows PC” on page 21.

To schedule the backup of a selected folder:

1. Open the SmartSYNC window.
2. Click the **Schedule** tab.
3. Click the **Create** button.
4. In the Backup Schedule window, verify the Destination.

   Destinations are identified by drive letters and correspond to a specific folder on the EdgeStore.
5. In the folder list, click the **+** icons to expand the tree.

   The Folder List is a representation of the file structure on your PC.
6. Click the folder you want to backup.

   A checkmark appears beside the selected folder. The backup will include the folder you select and all subfolders.
7. Click the **Next >>** button.
8. Choose a Schedule interval by number of hours, daily, or weekly.

9. Choose a setting:
   - If you chose hours, choose the number of hours from the dropdown menu.
   - If you chose daily, choose the time of day in the hour (24-hour clock) and minutes dropdown menu.
   - If you chose weekly, choose the time of day and day of the week in the hour (24-hour clock), minutes, and day dropdown menus.
10. Click the **Finish** button.

    Your Backup Schedule appears in the Schedule tab.

Also see “Chapter 4: One Touch Backup” on page 43.

Modifying a Backup Schedule

You can change source folders, time, and day settings for a scheduled Backup.

To modify a Backup Schedule:

1. Open the SmartSYNC window.
2. Click the **Schedule** tab.
3. In the Schedule list, highlight the schedule you want to modify.
4. Click the **Modify** button.
5. Choose the folders you want to backup from the tree, then click **Next >>**.
6. Choose the Schedule Type (hour, daily, weekly).
7. Choose the time and day settings.
8. Click **Finish** to save your Backup settings.

Deleting a Backup Schedule

To delete a Backup Schedule:

1. Open the SmartSYNC window.
2. Click the **Schedule** tab.
3. In the Schedule list, highlight the schedule you want to delete.
4. Click the **Delete** button.
5. In the confirmation box, click **Yes**.

Setting the Default Browser for EASM

To set the default browser for EASM:

1. Open the SmartSYNC window.
2. Click the Option menu and choose *Browser Path...*

   The Setup Browser Path dialog box displays.
3. Click the **...** button, then navigate to the browser's *.exe* file.
4. Highlight the browser's *.exe* file, then click the **Open** button.
5. Click the **OK** button to save your setting.

Viewing the Event Log

To view the Event Log:

1. Open the SmartSYNC window.
2. Click the **Event Log** tab.
3. From the Type menu, choose the type of events you want to display:
   - **All** – All events
   - **Info** – Information events only
   - **Error** – Error events only

Clearing the Event Log

To clear the Event Log:

1. Open the SmartSYNC window.
2. Click the **Event Log** tab.
3. Click the **Clear All** button.

Or, click the Event menu and choose *Clear All*.

Saving the Event Log to a Text File

To save the Event Log to a text file:

1. Open the SmartSYNC window.
2. Click the **Event Log** tab.
3. Click the **Save File** button (right).
4. In the Save dialog box, name the file, navigate to the folder where you want to save the log file, and click the **Save** button.

   A text file of the event log is saved to the your PC's hard drive.

Save File button

Chapter 6: EASM

- Connecting to EASM (below)
- Choosing a Language (page 62)
- Navigating in EASM (page 62)
- Setting up EdgeStore with the Setup Wizard (page 63)
- Managing Users and Groups (page 65)
- Managing File & Print Services (page 70)
- Managing RAID Volumes (page 79)
- Managing Backups (page 84)
- Managing the Network Connection (page 88)
- Making Management Settings (page 91)
- Managing Services (page 96)

Connecting to EASM

The Edge10 Advanced Storage Manager (EASM) software is factory-installed on the EdgeStore system. EASM runs in the browser on your PC. You can access EASM:

- Directly in your browser. See page 60.
- Through SmartSYNC. See page 61.

EASM in your Browser

To log into EASM in your browser:

1. Start your Browser.
2. In the Browser address field, type in the IP address of the EdgeStore.

   See “Finding the EdgeStore’s IP Address” on page 17.

   Note that the IP address shown below is only an example. The IP address you type into your browser will be different.

   - EASM uses an HTTP connection . . . . . .http://
   - Enter the EdgeStore’s IP address 192.168.1.110

   Together, your entry looks like this: **http://192.168.1.110**

   The EASM login screen displays.

3. Type the user name and password in the respective fields, then click the **Login** button.

   The default user name is **admin**. The default password is **admin**.

   The user name and password are case sensitive.

EASM in SmartSYNC

To log into EASM through SmartSYNC:

1. In the Windows application tray (lower right corner of the screen), double-click the **SmartSYNC** icon (right).

   SmartSYNC opens with the Server Information tab displayed.

2. Click the **Open GUI** button (right).

   Your default browser starts and the EASM login screen displays.

3. Type the user name and password in the respective fields, then click the **Login** button.

   The default user name is **admin**. The default password is **admin**.

   The user name and password are case sensitive.

Choosing a Language

To choose a language, click the Language menu in the EASM Header and choose the language you prefer.

Navigating in EASM

The Tree is the primary navigation tool in EASM. Categories of functions listed with a **+** sign before the icon.

Icons for specific functions are listed under the categories. Click the **+** sign to show the functions.



Click the function icons to display their information on the screen. Each function has one or more tabs in its screen.

Setting up EdgeStore with the Setup Wizard

If you used the NAS Setup Wizard utility to set up your EdgeStore, you do not need to run the Setup Wizard in EASM.

If you have not yet set up your EdgeStore:

1. In the Tree, click the **+** beside the **Wizard** icon, then on the **Setup Wizard** icon to display the Setup Wizard screen.
2. Click the **Next** button to start the Setup Wizard.

   The Step 1 screen appears.
3. Optional. In the Computer Name field, enter a name for the EdgeStore.

   Use only letters, numbers, and the underscore character for the name.
4. Under network configuration, choose one of the following options:
   - **Configure using DHCP** – Choose this option if your network has a DCHP server with addresses available
   - **Configure using Specify an IP address** – Choose this option if you want to set the IP address and other network setting manually
5. If you chose the *Configure using Specify an IP address* option, type the following information in the fields provided:
   - IP Address
   - Subnet Mask
   - Default Gateway IP Address
   - Primary DNS
   - Secondary DNS

   See your Network Administrator for help with these settings.
6. Click the **Next** button to continue.

   The Step 2 screen appears.
7. Optional. Type a new administrator password into the New Password field.

   Retype the new password into the Retype Password field.
8. Optional. To add a user, click the **Add new user** option button.
9. If you clicked the **Add new user** option button, type a user name and password into the fields provided, then click the **Add** button.
10. Click the **Next** button to continue.

    The Step 3 screen appears.

11. Check the Enable box to the right of the services you plan to use.
    - **Windows** – Enables file access from Windows PCs. Also required to use the EdgeStore as a print server.
    - **Unix/Linux** – Enables file access from Unix and Linux PCs
    - **Macintosh** – Enables file access from Macintosh PCs
    - **FTP** – Enables file access from PCs using FTP
12. Optional. Type new names into the Workgroup Name and Computer Description fields.
13. Click the **Next** button to continue.

    The Step 4 screen appears.

    You must add at least one folder, which you will access from your PC as a networked drive.
14. To add a folder, click the **Add new folder** option button.
15. Type a folder name into the field provided, check the boxes of the services you expect to use with this folder, then click the **Add** button.

    Add more folders as required.
16. Click the **Next** button to continue.

    The Step 5 screen appears.

    If a RAID Volume already exists on the EdgeStore, information about the RAID Volume is shown. To change the RAID, you must delete it first, then run the Setup Wizard again. See “Deleting a RAID Volume” on page 82.
17. From the RAID Level dropdown menu, choose the RAID level you want for your disk array.

    See for “Choosing a RAID Level” on page 106 more information.
18. Highlight disk drives in the Free Disks column and click the **>>** button to move them to the Disks in RAID column.
19. Click the **Next** button to continue.

    The Finish screen appears.
20. Click the **Finish** button to set up your EdgeStore.

    The setup process takes several minutes, depending on the size of your disk drives.

Managing Users and Groups

This category includes the following topics:

- Viewing a List of Users (page 65)
- Creating a User (page 65)
- Changing the Administrator's Password (page 65)
- Changing a User's Password (page 66)
- Deleting a User (page 66)
- Viewing a List of Groups (page 66)
- Creating a Group (page 67)
- Adding Members to a Group (page 67)
- Removing Members from a Group (page 67)
- Deleting a Group (page 68)
- Viewing Quotas (page 68)
- Setting Quotas (page 68)

Viewing a List of Users

To view the list of Users:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **User Management** icon.
   A list of users appears on the Information tab.

Creating a User

You can create up to 512 Users.

To create or add a new user:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **User Management** icon.
3. Click the **Create User** tab.
4. Type a user name in the field provided.
5. Type a password into the fields provided.
6. Click the **OK** button.

Changing the Administrator's Password

To change the Administrator's password:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **User Management** icon.

3. Click the **Change Password** tab.
4. Type a new password into the fields provided.
5. Click the **OK** button.

If you forget your new password, you reset the EdgeStore to the default Administrator's password. See "Restoring the Default Password" on page 124.

Changing a User's Password

To change a user's password:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **User Management** icon.
3. Click the **Change Password** tab.
4. From the User Name dropdown menu, choose the name of the user whose password you want to change.
5. Type a new password into the fields provided.
6. Click the **OK** button.

Deleting a User

You cannot delete the Administrator or the Guest. To delete any other user:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **User Management** icon.
3. Click the **Delete User** tab.
4. Click the option button to the left of the user you want to delete.
5. Click the **OK** button.
6. In the confirmation box, click the **OK** button.

Viewing a List of Groups

Groups are composed of users. You can assign permissions to a group, the same as you would do with individual users.

To view a list of groups:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Group Management** icon.

   A list of groups appears on the Information tab.

Creating a Group

Groups are composed of users. You can assign permissions to a group, the same as you would do with individual users. You can create up to 256 groups.

To create a group:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Group Management** icon.
3. Click the **Create** tab.
4. Type a group name in the field provided.
5. Click the **OK** button.

Adding Members to a Group

You must create a group before you can assign members to it. See “Creating a Group” on page 67.

To add members to a group:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Group Management** icon.
3. Click the **Group Members** tab.
4. From the dropdown menu, choose a group to which you want to add members.
5. Highlight users in the Users column and click the **>>** button to move them to the Members column.
6. Click the **OK** button.

Removing Members from a Group

To remove members from a group:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Group Management** icon.
3. Click the **Group Members** tab.
4. From the dropdown menu, choose a group from which you want to remove members
5. Highlight users in the Members column and click the **<<** button to move them to the Users column.
6. Click the **OK** button.

Deleting a Group

You must remove all members from the group before you can delete the group. See “Removing Members from a Group” on page 67.

To delete a group:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Group Management** icon.
3. Click the **Delete** tab.
4. Click the option button next to the group you want to delete.
5. Click the **OK** button.

Viewing Quotas

Quotas are portions of storage space that you assign to each user or group.

To view a quota:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Quota** icon.

   A list of users and groups, and the following data appear on the screen:

   - Currently assigned quotas
   - Free space
   - Used space

Setting Quotas

Quotas are portions of storage space that you assign to each user or group. Assigning quotas enables you to control how much storage space each user or group can access.

By default, each user and group is assigned an unlimited quota, meaning that any one user or group can access the entire storage space. In the Quota screen, the names of groups are preceded with a **@** symbol.

To set a quota:

1. In the Tree, click the **+** beside the **Users & Groups** icon.
2. Click the **Quota** icon.
3. Click the **Settings** tab.
4. Highlight the user or group whose quota you want to assign.
5. Click one of the following options:

   - Unlimited
   - Limited Quota

6. If you chose Limited Quota, type a number into the field provided.
   This number represents how many MB of data the user or group can access.
7. Click the **OK** button.

Note

If you set different size quotas for the user and the group, EdgeStore will use the smaller quota.

Managing File & Print Services

This category includes the following topics:

- Setting up Windows Access (page 70)
- Setting up UNIX/Linux Access (page 71)
- Setting up for Macintosh Access (page 72)
- Setting up for FTP Access (page 73)
- Setting up your Print Server (page 74)
- Setting up your DLNA Server (page 74)
- Viewing a List of Folders (page 75)
- Modifying Folder Services (page 75)
- Adding a Folder (page 76)
- Deleting a Folder (page 76)
- Setting up Windows Sharing for a Folder (page 77)
- Setting up UNIX and Linux Sharing for a Folder (page 77)
- Setting up FTP Sharing for a Folder (page 78)

Setting up Windows Access

Follow this procedure to set up access from a Windows PC:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Protocol Control** icon.
3. Click the **Windows** tab.
4. Click the **Enable** option button beside Services.
5. Optional. Type a new Computer Description into the field provided.
6. Choose the option button to make the EdgeStore a member of:
   - An Active Directory (AD) Domain
   - A Workgroup

   Note: If you join an AD Domain, you automatically disable your NIS Domain settings. See “Setting up UNIX/Linux Access” on page 71.
7. Optional. If you chose an AD Domain, enter the following in the fields provided:
   - Domain Name
   - Domain Controller
   - Administrator Name
   - Administrator Password

   See your Network Administrator for help with this information.

8. Optional. If you chose an Workgroup, enter the Workgroup name into the field provided:

   See your Network Administrator for help with this information.
9. Click the **OK** button to save your settings.
10. In the Tree, click the **+** beside the **Sharing Setup** icon.
11. Click the **Windows Sharing** tab.
12. Choose a folder from the Folder Name dropdown menu.
13. In the User/Group list, highlight the name of a user or group.

    Group names are preceded by the **@** character.
14. Under Permissions, choose a permission level for this user or group:
    - Deny Access
    - Read Only
    - Read and Write
15. Click the **OK** button to save your settings.

    You can now access the folder you chose from a Windows PC.

    See “Chapter 3: Connecting to the EdgeStore” on page 21 for information about the settings that you must make on your PC.

Note

Windows support is only through SMB and CIFS protocols. EdgeStore supports the Recycle Bin feature. When you delete a file, the file is moved to the Recycle Bin, a hidden folder in the share folder.

Setting up UNIX/Linux Access

Follow this procedure to set up access from a UNIX or Linux PC:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Protocol Control** icon.
3. Click the **UNIX/Linux** tab.
4. Click the **Enable** option button beside Services.
5. Optional. If you want to join a NIS Domain, click the **NIS Domain** option button.

   Note: If you join an NIS Domain, you automatically disable your AD Domain settings. See “Setting up Windows Access” on page 70.
6. Optional. If you chose to join a NIS Domain, enter the Domain name into the field provided.

   See your Network Administrator for help with this information.

7. Click the **OK** button to save your settings.
8. In the Tree, click the **+** beside the **File Sharing** icon.
9. Click the **Modify** tab.
10. From the Folder name dropdown menu, choose the folder you want to access.
11. Check the **UNIX/Linux** box.
12. Click the **OK** button to save your settings.
13. In the Tree, click the **+** beside the **Sharing Setup** icon.
14. Click the **UNIX/Linux Sharing** tab.
15. Choose a folder from the Folder Name dropdown menu.
16. In the New IP Address field, type the IP address of the UNIX or Linux PC from which you will access this folder, then click the **Add** button.

    You must designate the IP addresses for each folder individually. You can have up to 256 IP addresses for all of your folders.
17. Click the **OK** button to save your settings.

    You can now access the folder you chose from a UNIX or Linux PC.

    See “Chapter 3: Connecting to the EdgeStore” on page 21 for information about the settings that you must make on your PC.

Setting up for Macintosh Access

Follow this procedure to set up access from a Macintosh PC:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Protocol Control** icon.
3. Click the **Macintosh** tab.
4. Click the **Enable** option button beside Services.
5. Click the **OK** button to save your settings.
6. In the Tree, click the **+** beside the **File Sharing** icon.
7. Click the **Modify** tab.
8. From the Folder name dropdown menu, choose the folder you want to access.
9. Check the **Macintosh** box.
10. Click the **OK** button to save your settings.

    You can now access the specified folder from a Macintosh PC.

    See “Chapter 3: Connecting to the EdgeStore” on page 21 for information about the settings that you must make on your PC.

Setting up for FTP Access

Follow this procedure to set up FTP access for your folders:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Protocol Control** icon.
3. Click the **FTP Sharing** tab.
4. Click the **Enable** option button beside Services.
5. Type a Command Port number into the field provided.

   Port 21 is typically used for the Command Port.
6. Optional. If you want to specify a range of passive data port numbers, type those numbers into the fields provided.

   The port range is 1024 to 65535.

   Be sure the port numbers you enter are enabled on your firewall and server.

   In active mode, the FTP server uses port 20 for the data port.
7. Optional. If your FTP client uses double-byte characters but does not support Unicode, choose your FTP client's encoding from the Client Coding Type dropdown menu. Choose from:
   - Unicode
   - Shift-JIS
   - GB2312
   - BIG5
8. Click the **OK** button to save your settings.
9. In the Tree, click the **+** beside the **File Sharing** icon.
10. Click the **Modify** tab.
11. From the Folder name dropdown menu, choose the folder you want to access.
12. Check the **FTP** box.
13. Click the **OK** button to save your settings.

    You can now access the specified folder from your PC using FTP.

Setting up your Print Server

Follow this procedure to set up the EdgeStore as a printer server:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Protocol Control** icon.
3. Click the **Windows** tab.
4. Click the **Enable** option button beside Services.
5. Click the **OK** button to save your settings.
6. Click the **Printer Server** tab.
7. Click the **Enable** option button beside Printer Server.
8. Click the **OK** button to save your settings.

Notes

- The Printer Server tab also verifies that your USB printer is connected and online. If you do not see your printer on the Printer Server tab, take the necessary action to connect and power the printer. See “Connecting a USB Printer to EdgeStore” on page 31.
- The software driver for your printer must be installed on your PC before you can print from the PC. See the printer’s *Setup Guide* or *User Manual*.

Setting up your DLNA Server

The Digital Living Network Alliance (DLNA) service enables the Universal Plug-and-Play (UPnP) protocol, so your EdgeStore can function as a Digital Media Server (DMS). When your DLNA service is enabled, you can connect your DLNA control unit or UPnP client on the network where the EdgeStore is connected, and use the EdgeStore to play image, audio, and AV media.

You must install the optional DLNA plug-in before you can make this setting and use the UPnP protocol. See “Installing Application Plug-ins” on page 145.

Follow this procedure to set up the EdgeStore as a DLNA server:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Protocol Control** icon.
3. Click the **DLNA Server** tab.
4. Click the **Enable** option button beside Services.
5. Click the **OK** button to save your settings.

The media content directory is /VOLUME1/PLUGINAPP/DLNA/. This is a shared folder created when you install the DLNA plug-in. The directory has three sub-directories: PICTURE, MUSIC, and VIDEO.

With the DLNA plug-in, EdgeStore supports these media formats:

- **Picture** – bmp, gif, jpg, jpeg, png, tif
- **Music** – mp3, pcm, wma
- **Video** – avi, mpg, mpeg, wmv, tts, vob

Viewing a List of Folders

A folder is the entity that appears as a Network Drive on your PC.

To view the list of folders:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **File Sharing** icon.

   A list of current folders appears in the Information tab.

Modifying Folder Services

Services enable different types of PCs to access your folders. Use this function to add or remove a service for a specific folder.

To modify the services on a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **File Sharing** icon.
3. Click the **Modify** tab
4. From the Volume dropdown menu, choose the RAID Volume containing the folder you want to modify.
5. From the Folder Name dropdown menu, choose the folder you want to modify.
6. Check the boxes beside the services you want to use.
7. Click the **OK** button.

   If the service you want is OFF, see:

   “Setting up Windows Access” on page 70

   “Setting up UNIX/Linux Access” on page 71

   “Setting up for Macintosh Access” on page 72

   “Setting up for FTP Access” on page 73

Adding a Folder

A folder is the entity that appears as a Network Drive on your PC.

To add a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **File Sharing** icon.
3. Click the **Create** tab.
4. From the Volume dropdown menu, choose the RAID Volume in which you want to create a new folder.
5. In the Folder Name field, type a name for your new folder.
6. Check the boxes beside the services you want to use.
7. Click the **OK** button.

   To access the new folder from a Windows PC, see “Setting up Windows Sharing for a Folder” on page 77.

   To access the new folder from a UNIX or Linux PC, see “Setting up UNIX and Linux Sharing for a Folder” on page 77.

   To make the folder a network drive on your PC, see “Chapter 3: Connecting to the EdgeStore” on page 21.

Deleting a Folder

Caution

When you delete a folder, you delete all the data saved in the folder. Back up any important data before you delete a folder.

To delete a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **File Sharing** icon.
3. Click the **Remove** tab
4. Click the option button beside the folder you want to delete.
5. Click the **OK** button.
6. In the confirmation box, click the **OK** button to confirm.

Setting up Windows Sharing for a Folder

Windows sharing assigns user access the folders on your EdgeStore. By default all users and groups have read-only access.

To set up Windows sharing for a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Sharing Setup** icon.
3. Click the **Windows Sharing** tab.
4. From the Volume dropdown menu, choose the RAID Volume containing the folder you want to modify.
5. From the Folder Name dropdown menu, choose the folder you want to modify.
6. In the Permission list, click the option button for one of the following permissions for each group and user:
   - Deny Access
   - Read Only
   - Read and Write
7. Click the **OK** button.

   Be sure the Windows service is running for this folder. See “Setting up Windows Access” on page 70.

Setting up UNIX and Linux Sharing for a Folder

UNIX and Linux sharing designates which UNIX and Linux PCs can access the folders on your EdgeStore. You specify a UNIX or Linux PC by its IP address. You can add up to 256 IP addresses for all of your folders.

You must designate the IP addresses for each folder individually.

To set up UNIX and Linux sharing for a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Sharing Setup** icon in the tree.
3. Click the **UNIX/Linux Sharing** tab.
4. From the Volume dropdown menu, choose the RAID Volume containing the folder you want to modify.
5. From the Folder Name dropdown menu, choose the folder you want to modify.
6. In the New IP Address field, type the IIP address of the UNIX or Linux PC from which you will access this folder.
7. Click the **Add** button.

Be sure the UNIX/Linux service is running for this folder. See “Setting up UNIX/Linux Access” on page 71.

Setting up FTP Sharing for a Folder

FTP sharing assigns user access the folders on your EdgeStore. By default all users and groups have read-only access.

To set up FTP sharing for a folder:

1. In the Tree, click the **+** beside the **File & Print** icon.
2. Click the **Sharing Setup** icon.
3. Click the **FTP Sharing** tab.
4. From the Volume dropdown menu, choose the RAID Volume containing the folder you want to modify.
5. From the Folder Name dropdown menu, choose the folder you want to modify.
6. In the Permission list, click the option button for one of the following permissions for each group and user:
   - Deny Access
   - Read Only
   - Read and Write
7. Click the **OK** button.

   Be sure the FTP service is running for this folder. See “Setting up for FTP Access” on page 73.

Managing RAID Volumes

This category includes the following topics:

- Viewing RAID Volume Status (page 79)
- Viewing Disk Drive Information (page 80)
- Creating a RAID Volume (page 80)
- Designating a Spare Drive (page 81)
- Migrating a RAID Volume (page 81)
- Deleting a RAID Volume (page 82)
- Viewing an External USB Drive or Memory Stick (page 83)
- Formatting an External USB Drive or Memory Stick (page 83)

Viewing RAID Volume Status

RAID status refers to the disk drives on your EdgeStore and how they are arranged into a RAID Volume.

To view the status of your RAID Volume:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.

   The RAID Status tab displays the current RAID system and its status:

   - **RAID Name** – The name of your RAID, automatically assigned when it was created
   - **RAID Level** – RAID 0, 1, 5, or 10, specified when it was created
   - **Capacity** – Data capacity of the RAID Volume in GB
   - **RAID Status** – Functional is normal. Critical means a disk drive has failed. Offline means you cannot access your data.

     Critical and offline RAIDs require you to take corrective action. See “Replacing a Failed Disk Drive” on page 113.
   - **Action Status** – Idle is normal. Rebuilding means the RAID Volume is being rebuilt after a disk drive failure. Migrating means the RAID Volume is adding a disk drive or changing RAID levels.
   - **Background Activity** – None is normal. Running means a background activity is in progress.

Viewing Disk Drive Information

To view information about a disk drive:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.

   The RAID Status tab displays the current RAID system and its status.
3. In the Disk List, double-click a disk drive icon.

   The disk drive information displays under Disk Status.

Creating a RAID Volume

On EdgeStore, the term RAID Volume refers to one or more disk drives working together as a RAID logical drive.

You can also use a USB disk to create a RAID Volume. See “Viewing an External USB Drive or Memory Stick” on page 83.

You must have unassigned disk drives in your EdgeStore to create a new RAID.

To create a new RAID Volume:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.
3. Click the **Create** tab.
4. From the RAID Level dropdown menu, choose the RAID level you prefer for your disk array.

   See “Choosing a RAID Level” on page 106 for more information.
5. Highlight disk drives in the Free Disks column and click the **>>** button to move them to the Disks in RAID column.
6. Click the **OK** button.

   The RAID Volume is created and formatting begins. Formatting requires several minutes, depending on the size of your disk drives.

   After formatting is done, you must create folders on your RAID Volume. See “Adding a Folder” on page 76.

Designating a Spare Drive

If you have an unassigned disk drive, you can assign it as a spare drive.

For more information, see “Spare Drive” on page 107 and “Automatic Rebuilding” on page 108.

To assign a spare drive:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.
3. Click the **Create** tab.
4. From the RAID Level dropdown menu, choose *Spare Disk*.
5. Highlight a disk drive in the Free Disks column and click the **>>** button to move it to the Disks in RAID column.
6. Click the **OK** button.

Migrating a RAID Volume

To migrate a RAID Volume means to change its RAID level or to add disk drives. See “RAID Volume Migration” on page 109 for more information.

To migrate a RAID Volume:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.
3. Click the **Modify** tab.
4. From the Current Volume dropdown menu, choose the RAID Volume which you want to modify.
5. In the Migrate to RAID Level dropdown menu, choose the target RAID Level.
6. To add disk drives, highlight disk drives in the Free Disks column and click the **>>** button to move them to the Disks in RAID column.
7. Click the **OK** button.

   The RAID Volume is modified as you directed. Migration requires several minutes, depending on the type of modification taking place and the size of your disk drives.

   During the modification, your RAID Volume and all of the folders on it are fully accessible.

   After the Migration is completed, you must extend the file system in order to use the storage space you have added. You can extend the file system immediately or wait until later.
8. Click the **File System Management** icon.
9. In the File System Status tab, click the **Extend File System** button.

Deleting a RAID Volume

Caution

When you delete a RAID Volume, you delete all the folders in the RAID volume and all the data saved in the folders. Back up any important data before you delete a RAID Volume.

Note

You cannot delete a RAID Volume while a background activity is running, such as Migration or Rebuild. Wait until these activities are completed.

To delete a RAID Volume:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.
3. Click the **Delete** tab.
4. Click the option button beside the RAID Volume you want to delete.
5. Click the **OK** button.
6. In the confirmation box, type **yes** into the field provided, then click the **OK** button.

   After a RAID Volume is deleted, the EdgeStore reboots automatically. When the EdgeStore is fully booted:

   - The System Status LED turns green (right)
   - The buzzer beeps one time (if the buzzer is enabled)



7. Close your browser then restart the browser to access EASM.

Viewing an External USB Drive or Memory Stick

To view a USB drive or memory stick attached to the EdgeStore:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.

   The USB drive or memory stick appears as a USB External Disk
3. Click the **File System Management** icon.

   The USB drive or memory stick appears as a Volume called USBDISK.

You do NOT create a RAID Volume or folders with the USB drive or memory stick as you would with the disk drives installed in the EdgeStore enclosure.

With the USB drive or memory stick connected to the EdgeStore, create a network drive on your PC and choose the USB disk as the folder. Then you can access the USB drive or memory stick from your PC.

See “Chapter 3: Connecting to the EdgeStore” on page 21 for more information.

Formatting an External USB Drive or Memory Stick

This option only appears when EdgeStore does not recognize the file system on the USB drive or memory stick.

Caution

When you format a USB drive or memory stick, you delete all the data saved on it. Back up any important data before you format.

To format a USB drive or memory stick:

1. Attach the USB drive or memory stick to one of the USB ports on the back of the EdgeStore.
2. In the Tree, click the **+** beside the **RAID & File System** icon.
3. Click the **File System Management** icon.
4. On the File System Status tab, highlight the USB drive.
5. From the Format File System Type dropdown menu, choose a file system:
   - **FAT 32** – Use for Windows, Linux, and Macintosh PCs, and EdgeStore
   - **Ext3** – Use for UNIX and Linux PCs, and EdgeStore
6. Click the **Format USB Disk** button.
7. In the confirmation box, type **yes**, then click the **OK** button.

Formatting requires several minutes, depending on the size of your USB drive or memory stick.

Managing Backups

This category includes the following topics:

- Viewing a List of Snapshot Backups (page 84)
- Setting up a Snapshot Backup (page 84)
- Scheduling a Snapshot Backup (page 85)
- Recovering Snapshot Backups (page 85)
- Viewing the NAS Replication Schedule (page 86)
- Setting up NAS Replication (page 86)
- Enabling One Touch Backup (page 87)

Viewing a List of Snapshot Backups

To view the list of Snapshot backups:

1. In the Tree, click the **+** beside the **Backup** icon.
2. Click the **Snapshot Backup** icon.

   The current list of Snapshots displays on the Information tab.

Setting up a Snapshot Backup

Caution

Setting up a Snapshot will delete all existing Snapshots.

To setup a Snapshot Backup:

1. In the Tree, click the **+** beside the **Backup** icon.
2. Click the **Snapshot Backup** icon.
3. Click the **Setup** tab.
4. From the Volume dropdown menu, choose the RAID Volume you want to backup.
5. Next to Snapshot Status, click the **Enable** option.
6. In the Reserve Capacity dropdown menu, choose a portion in GB of the RAID Volume you want to reserve for snapshots.
7. Click the **OK** button.
8. In the confirmation box, type **yes** into the filed provided than click the **OK** button.

   The snapshot backup settings are applied. The process takes a few moments. Click the **Schedule** tab for scheduling options.

Scheduling a Snapshot Backup

To schedule a Snapshot Backup:

1. In the Tree, click the **+** beside the **Backup** icon.
2. Click the **Snapshot Backup** icon.
3. Click the **Schedule** tab.
4. Click the option you want from the Schedule Type list.
   - **Disable** – No snapshots will be taken.
   - **Do it at once** – Snapshots will be taken now, one time only.
   - **Time interval by hour** – Snapshots will be taken at the hourly interval you choose from the dropdown menu.
   - **Daily** – Snapshots will be taken at the time of day you choose from the dropdown menus.
   - **Weekly** – Snapshots will be taken on the day of the week, at the time of day you choose from the dropdown menus.
5. As needed, make your choices from the dropdown menus.
6. Click the **OK** button.

   The new backup schedule is applied. If you have not yet made your Snapshot settings, click the **Setup** tab and make them now.

Recovering Snapshot Backups

The Snapshot recovery feature has two functions:

- Use a Snapshot to restore the data volume (VOLUME1 or VOLUMEx) to an earlier point in time.
- Export a Snapshot to the share folder. The recovered Snapshot volume is read-only.

To recover a Snapshot backup:

1. In the Tree, click the **+** beside the **Backup** icon.
2. Click the **Snapshot Backup** icon.
3. Click the **Recovery** tab.
4. Click the option button beside the Timestamp and Volume that you want to recover or export.
5. Do one of the following actions:
   - To restore the data volume using the Snapshot, click the **OK** button.
   - To export the Snapshot to the share folder, click the **Export** button.

   EdgeStore performs the action you specified.

Viewing the NAS Replication Schedule

NAS Replication is a feature that uses one EdgeStore to backup the data on another EdgeStore. The two EdgeStore systems must be on the same network.

To view the NAS Replication schedule:

1. In the Tree, click the **+** beside the **Backup** icon.
2. Click the **NAS Replication** icon.

   The current schedule displays on the Information tab.

   - **Role:**

     Standalone – No backup server was specified

     Primary Server – This EdgeStore is the primary, the other EdgeStore is the backup

     Backup Server – This EdgeStore is the backup, the other EdgeStore is the primary
   - **Primary or Backup Server** – The IP address of the other EdgeStore on the network.
   - **Schedule** – Replication schedule in number of hours, daily or weekly. Appears on the primary server.

Setting up NAS Replication

To set up NAS replication:

1. In the Tree, click the **+** beside the **Backup** icon.
2. Click the **NAS Replication** icon.
3. Click the **Setup** tab.
4. Under Settings, click the option button to assign a role to this EdgeStore:
   - **Standalone** – Use this option when you only have one EdgeStore on your network. This is the default setting and it disables NAS Replication.
   - **Primary** – This EdgeStore is the primary and the other EdgeStore is the backup server.
   - **Backup Server** – The other EdgeStore is the primary and this EdgeStore is the backup server.
5. Optional. If you chose Primary or Backup Server, type the IP address of the other EdgeStore on your network.

6. Under Schedule, click the option button for the schedule type you want:
   - **Disable** – Disables NAS Replication
   - **Do it at once** – Performs a NAS Replication when you click the **OK** button.
   - **Time interval by hour** – Set an hourly interval for NAS Replications to happen.
   - **Daily** – Sets the time of day when the NAS Replications happen.
   - **Weekly** – Sets the time of day and day of the week when the NAS Replications happen.
7. Click the **OK** button.

Enabling One Touch Backup

One Touch Backup is a feature that enables you to backup specified folders from your PC to the EdgeStore by pressing a button on the front of the EdgeStore.



To enable One Touch Backup:

1. In the Tree, click the **+** beside the **Backup** icon.
2. Click the **Client Backup** icon.
3. In the One Touch Backup tab, click the **Enable** option.
4. Click the **OK** button.

To disable One Touch Backup, click the **Disable** option, then click the **OK** button.

See “Chapter 4: One Touch Backup” on page 43.

Managing the Network Connection

This category includes the following topics:

- Viewing Network Setup Information (page 88)
- Making Network Settings (page 88)
- Working with Jumbo Frames (page 89)
- Setting up your DDNS Service (page 90)

Viewing Network Setup Information

To view network setup information:

1. In the Tree, click the **+** beside the **Network** icon.
2. Click the **Network Setup** icon.

   The current network setup for this EdgeStore displays on the Information tab:

   - Computer Name
   - IP Address
   - Subnet Mask
   - Default Gateway IP Address
   - Primary Domain Name Server IP Address
   - Secondary Domain Name Server IP Address

   To change these settings, click the **Setup** tab.

Making Network Settings

To make network settings:

3. In the Tree, click the **+** beside the **Network** icon.
4. Click the **Network Setup** icon.
5. Click the **Setup** tab.
6. Optional. Type a name for the EdgeStore in the Computer Name field.
7. Click an option button to choose an Internet Protocol option:

   - **Obtain an IP address automatically** – Choose this option to let your DHCP server make the network settings.
   - **Specify an IP address** – Choose this option if you want to make your network settings manually.

8. Optional. If you chose *Specify an IP address*, enter the following settings in the fields provided:
   - IP Address
   - Subnet Mask
   - Default Gateway IP Address
   - Primary Domain Name Server IP Address
   - Secondary Domain Name Server IP Address

   See your Network Administrator for help in making these settings.
9. Click the **OK** button to save your settings.

Working with Jumbo Frames

The term *jumbo frame* refers to a frame on a local area network that is larger than the standard 1518 byte size. EdgeStore supports jumbo frames up to 9000 bytes.

On EdgeStore, the frame size setting is called Maximum Transmission Unit (MTU). The default MTU or frame is 1500 bytes. This setting is appropriate for most users. See your Network Administrator before you change this setting.

To make frame size settings:

1. In the Tree, click the **+** beside the **Network** icon.
2. Click the **Network Setup** icon.
3. Click the **Jumbo Frame** tab.
4. From the MTU dropdown menu, choose the maximum MTU or frame size:
   - 1500 bytes (default)
   - 4000 bytes
   - 7000 bytes
   - 9000 bytes
5. Click the **OK** button to save your setting.

Setting up your DDNS Service

The Dynamic Domain Name Server service enables you to keep the same domain name even though your IP address changes.

You must register with Dynamic Network Services in order to obtain your domain name, user name, and password.

Follow this procedure to set up the DDNS service:

1. In the Tree, click the **+** beside the **Network** icon.
2. Click the **Network Setup** icon.
3. Click the **DDNS** tab.
4. Click the **Enable** option button beside Services.
5. Enter your domain name in the DDNS Name field.
6. Enter your User Name and Password in the fields provided.
7. Click the **OK** button to save your settings.

   Your DDNS service is now active.

Making Management Settings

This category includes the following topics:

- Viewing Service Status (page 91)
- Viewing the Event Log (page 92)
- Setting up SMTP Authentication (page 92)
- Viewing the Email Alert List (page 93)
- Adding an Email Alert Recipient (page 93)
- Deleting an Email Alert Recipient (page 93)
- Upgrading the System Firmware (page 93)
- Enabling and Disabling the Buzzer (page 94)
- Viewing UPS Status (page 94)
- Setting up a UPS (page 95)

Viewing Service Status

The EdgeStore runs services to enable PCs to access the folders on the EdgeStore and to work as a print server.

To view Service Status:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Service Status** icon.

   The status of each service displays on the Information tab.

   - **ON** – The service is running.
   - **OFF** – The service is not running.
3. If the service you want is OFF, click the **Enable** button to the right of the Service.

   Also see:

   “Setting up Windows Access” on page 70

   “Setting up UNIX/Linux Access” on page 71

   “Setting up for Macintosh Access” on page 72

   “Setting up for FTP Access” on page 73

   “Setting up your Print Server” on page 74

   “Setting up your DLNA Server” on page 74

   “Setting up your DDNS Service” on page 90

Viewing the Event Log

The event log keeps a log of the 20 most recent events on the EdgeStore. You can use this information to review your actions and to diagnose problems.

To view the Event Log:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Event Log** icon.

   A list of the 20 most recent events displays on the Event Log tab.

   Events are ranked in severity as Information, Warning, and Error.

Setting up SMTP Authentication

In order to set up email alerts over a network, you must enable the SMTP service, specify a SMTP server, and in most cases, supply authentication information. See your Network Administrator for help with these settings.

To set up SMTP authentication:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Mail Alert** icon.
3. Click the **Setup** tab.
4. Next to Service, click the **Enable** option button.
5. In the SMTP Server field, type the IP address or the DNS name of your SMTP server.
6. In the From field, the sender's email address that you want to appear in the alert messages.
7. Next to SMTP Authentication:
   - Click the **Yes** option button to enable authentication.
   - Click the **No** option button to disable authentication.

   Note that most SMTP servers require authentication.
8. If you enabled authentication, to the following:
   - In the User Name field, type the mail server account name.
   - In the Password field, type the password of the mailer server account.
9. Click the **OK** button.

Viewing the Email Alert List

The EdgeStore will send alerts via email to the recipients you designate.

To view a list of Email Alert recipients:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Mail Alert** icon.

   The list of recipients displays on the Mail List tab.

   See “Checking Your Email Inbox” on page 124 for an example of an email alert message.

Adding an Email Alert Recipient

You can have up to 32 Email Alert recipients.

To add an Email Alert recipient:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Mail Alert** icon.
3. Click the **Add** tab.
4. In the E-Mail Address field, type the recipient’s email address.
5. Click the **OK** button.

Deleting an Email Alert Recipient

To delete an Email Alert recipient:

6. In the Tree, click the **+** beside the **Management** icon.
7. Click the **Mail Alert** icon.
8. Click the **Delete** tab.
9. Click the option button beside the E-Mail Address you want to delete.
10. Click the **OK** button.
11. In the confirmation box, click the **OK** button.

Upgrading the System Firmware

See “Upgrading the Firmware” on page 143.

Installing an Application Plug-in

See “Installing Application Plug-ins” on page 145.

Enabling and Disabling the Buzzer

The EdgeStore has a buzzer that sounds when the EdgeStore is finished booting and when a problem is detected. The buzzer is enabled by default.

Edge10 recommends that you leave the buzzer enabled.

To disable the buzzer:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **Buzzer** icon.
3. Click the **Disable** option button.
4. Click the **OK** button.

Click the **Enable** option button, then click the **OK** button to enable the buzzer.

Viewing UPS Status

If you have an APC Uninterruptable Power Supply (UPS) attached to the EdgeStore, you can check its status in EASM.

To view UPS status:

1. In the Tree, click the **+** beside the **Management** icon.
2. Click the **APC UPS** icon.

   The Information tab displays the status of the UPS.

   If there is no UPS connected or recognized, the Status field reports "NO UPS."

Setting up a UPS

To set up a UPS:

1. Attach the APC UPS to one of the EdgeStore's USB ports.
2. In the Tree, click the **+** beside the **Management** icon.
3. Click the **APC UPS** icon.
4. Click the **Setup** tab.

   The Setup tab enables you to tell the EdgeStore how and when to shutdown after a power failure.

   Click the option button beside the shutdown option you want:

   - Disable (the EdgeStore will continue to run until the UPS battery is depleted)
   - Shutdown when the UPS reaches a set percentage of reserve power
   - Shutdown when the UPS reaches a set number of minutes of remaining runtime
   - Shutdown after running on the UPS batteries for a set number of minutes
5. Optional. If you chose battery percentage, type a percentage amount in the % field.
6. Optional. If you chose remaining runtime or running on batteries, type the number of minutes into the Mins. field.
7. Click the **OK** button.

Managing Services

This category includes the following topics:

- Setting System Date and Time (page 96)
- Running the Network Time Protocol (page 96)
- Viewing the Results of NTP Synchronization (page 97)
- Rebooting the EdgeStore (page 97)
- Shutting Down the EdgeStore (page 98)
- Restarting the EdgeStore (page 98)
- Locating the EdgeStore (page 98)
- Viewing System Information (page 99)
- Viewing Enclosure Information (page 99)

Setting System Date and Time

1. To set the date and time on the EdgeStore:
   In the Tree, click the **+** beside the **System** icon.
2. Click the **Date / Time** icon.
3. Click the **Setup** tab.
4. From the dropdown menus, choose the time and date values.
5. Click the **OK** button.

Running the Network Time Protocol

You can use the Network Time Protocol (NTP) to set the system date and time on your EdgeStore to synchronize itself with an external Time Server.

To run the Network Time Protocol:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **Date / Time** icon.
3. Click the **Time Zone** tab.
4. From the dropdown menu, choose the time zone for your location.
5. Click the **OK** button.
6. Click the **NTP** tab.
7. In the Time Server field, type the URL of the time server you want to use.
   URL *time.nist.gov* is the default.

8. Under Schedule, choose one of the options:
   - **Disable** – Disables NTP synchronization
   - **Do it at once** – Performs a synchronization when you click the OK button.
   - **Time interval by hour** – Set an hourly interval for a synchronization to happen.
   - **Daily** – Sets the time of day when the synchronization happens.
   - **Weekly** – Sets the time of day and day of the week when the synchronization happens.
9. Click the **OK** button.

Viewing the Results of NTP Synchronization

To view the results of an NTP synchronization:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **Date / Time** icon.
3. Click the **NTP** tab.

   The results of the latest synchronization are displayed:
   - **Last Synchronization Time** – Time and date of the last synchronization
   - **Last Synchronization Result** – OK means success

Rebooting the EdgeStore

Normally you will only need to reboot the EdgeStore is after a firmware upgrade or a plug-in installation. See “Upgrading the Firmware” on page 143. During the reboot, none of your folders will be accessible from your networked PCs.

To reboot the EdgeStore:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **Reboot / Shutdown** icon.
3. Click the **Reboot** option.
4. Click the **OK** button.
5. In the confirmation box, click the **OK** button.

   The reboot runs automatically. When the EdgeStore is fully booted:
   - The system status LED turns green (right)
   - The buzzer beeps one time (if the buzzer is enabled)

   See “Enabling and Disabling the Buzzer” on page 94.



Shutting Down the EdgeStore

The only time you need to shut down the EdgeStore is to replace the disk drive cooling fan or the power supply. See “Appendix B: Maintenance” on page 143.

During and after the shutdown, none of your folders will be accessible from your networked PCs.

Using EASM

To shut down the EdgeStore:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **Reboot / Shutdown** icon.
3. Click the **Shutdown** option.
4. Click the **OK** button.
5. In the confirmation box, click the **OK** button.

Directly

To shut down the EdgeStore, press and hold the power button for five seconds. The system status LED turns red, then goes dark (right).



Restarting the EdgeStore

To restart the EdgeStore after a shutdown, press the power button on the front of the EdgeStore chassis (right).

When the EdgeStore is fully booted:

- The system status LED turns green (right)
- The buzzer beeps one time (if the buzzer is enabled)

See “Enabling and Disabling the Buzzer” on page 94.

Locating the EdgeStore

If your EdgeStore in is on a rack with other equipment and you need to locate it quickly, this function will assist you.

To locate the EdgeStore:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **System Information** icon.
3. Click the **System Information** tab.
4. Click the **Locate** button.

   The EdgeStore’s buzzer beeps three times and the system status LED blinks three times (right).



Viewing System Information

To view system information:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **System Information** icon.
3. Click the **System Information** tab.

   System Information includes:

   - **Operating System** – Embedded Linux
   - **Firmware Version** – Changes when you upgrade the firmware. See “Upgrading the Firmware” on page 143
   - **CPU model** – MPC 8343
   - **Network Adapter** – Gigabit Ethernet
   - **Network Flow** – Inflow and Outflow speeds in bits per second

Viewing Enclosure Information

To view enclosure information:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **System Information** icon.
3. Click the **Enclosure Information** tab.

   Enclosure Information includes:

   - CPU temperature
   - System temperature
   - System Fan Speed
   - Power Status 5V
   - Power Status 12V
   - Power Status 3.3V

   If any values are out of specification, see “Checking Enclosure Status in EASM” on page 120.

Chapter 7: Technology Background

- Introduction to RAID (below)
- Choosing a RAID Level (page 106)
- Spare Drive (page 107)
- Partition and Format (page 108)
- RAID Volume Migration (page 109)

Introduction to RAID

RAID (Redundant Array of Independent Disks) allows multiple disk drives to be combined together into a RAID Volume. You create a RAID Volume on your EdgeStore when you perform the setup procedure, either in the NAS Setup Wizard or the EASM Setup Wizard.

The benefits of a RAID can include:

- Higher data transfer rates for increased server performance
- Increased overall storage capacity for a single Volume
- Data redundancy/fault tolerance for ensuring continuous system operation in the event of a disk drive failure

Different RAID levels use different organizational models and have varying benefits. Also see “Choosing a RAID Level” on page 106. The following outline breaks down the properties for each RAID level supported on the EdgeStore:

RAID 0 – Stripe

When a RAID Volume is striped, the read and write blocks of data are interleaved between the sectors of multiple disk drives. Performance is increased, since the workload is balanced between drives or “members” that form the RAID Volume. Identical drives are recommended for performance as well as data storage efficiency.



Figure 1. RAID 0 Striping interleaves data across multiple drives

The RAID Volume’s data capacity equals the capacity of the smallest disk drive times the number of disk drives. For example, one 100 GB and three 120 GB drives will form a 400 GB (4 x 100 GB) RAID Volume instead of 460 GB.

If disk drives of different capacities are used, there will also be unused capacity on the larger drives.

Because RAID 0 does not offer Fault Tolerance, meaning that you cannot recover your data after a disk drive failure, Edge10 does not recommend a RAID 0 Volume for your EdgeStore.

RAID 0 Volumes on EdgeStore consist of one or more disk drives.

RAID 1 – Mirror

When a RAID Volume is mirrored, identical data is written to a pair of disk drives, while reads are performed in parallel. The reads are performed using elevator seek and load balancing techniques where the workload is distributed in the most efficient manner. Whichever drive is not busy and is positioned closer to the data will be accessed first.

With RAID 1, if one disk drive fails or has errors, the other mirrored disk drive continues to function. This is called Fault Tolerance. Moreover, if a spare disk drive is present, the spare drive will be used as the replacement drive and data will begin to be mirrored to it from the remaining good drive.



Figure 2. RAID 1 Mirrors identical data to two drives

The RAID Volume's data capacity equals the smaller disk drive. For example, a 100 GB disk drive and a 120 GB disk drive have a combined capacity of 100 GB in a mirrored RAID Volume.

If disk drives of different capacities are used, there will also be unused capacity on the larger drive.

RAID 1 Volumes on EdgeStore consist of two disk drives.

If you want a mirrored RAID Volume with more than two disk drives, see "RAID 10 – Mirror / Stripe" on page 105.

RAID 5 – Block Striping with Distributed Parity

RAID 5 organizes block data and parity data across the disk drives. Generally, RAID level 5 tends to exhibit lower random write performance due to the heavy workload of parity recalculation for each I/O. RAID 5 works well for file, database, application and web servers.



Figure 3. RAID 5 Stripes all drives with data and parity information

The capacity of a RAID 5 Volume equals the smallest disk drive times the number of disk drives, minus one. Hence, a RAID 5 Volume with four 100 GB disk drives will have a capacity of 300 GB. A RAID Volume with two 120 GB disk drives and one 100 GB disk drive will have a capacity of 200 GB.

RAID 5 is generally considered to be the most versatile RAID level.

RAID 5 requires a minimum of three disk drives.

RAID 10 – Mirror / Stripe

Mirror/Stripe combines both of the RAID 0 and RAID 1 types. RAID 10 can increase performance by reading and writing data in parallel while protecting data with duplication. At least four disk drives are needed for RAID 10 to be installed. With a four-disk-drive RAID Volume, one drive pair is mirrored together then striped over a second drive pair.



Figure 4. RAID 10 takes a data mirror on one drive pair and stripes it over two drive pairs

The data capacity RAID 10 Volume equals the capacity of the smallest disk drive times the number of disk drives, divided by two.

In some cases, RAID 10 offers double fault tolerance, depending on which disk drives fail.

RAID 10 Volumes on EdgeStore consist of four disk drives.

Because all of the available disk drives are used for the RAID Volume, you cannot set up a spare drive with RAID 10.

Choosing a RAID Level

There are several issues to consider when choosing the RAID level for your Volume. The following discussion summarizes some advantages, disadvantages and applications for each choice.

RAID 0

Advantages	Disadvantages
Implements a striped disk RAID Volume, the data is broken down into blocks and each block is written to a separate disk drive I/O performance is greatly improved by spreading the I/O load across many channels and drives No parity calculation overhead is involved	Not a true RAID because it is not fault-tolerant The failure of just one drive will result in all data in an RAID Volume being lost Should not be used in mission critical environments

Recommended applications for RAID 0:

- Image Editing
- Pre-Press Applications
- Any application requiring high bandwidth

RAID 1

Advantages	Disadvantages
Simplest RAID storage subsystem design Can increase read performance by processing data requests in parallel since the same data resides on two different drives	Very high disk overhead - uses only 50% of total capacity

Recommended applications for RAID 1:

- Accounting/Financial
- Payroll
- Any application requiring very high availability

RAID 5

Advantages	Disadvantages
High Read data transaction rate Medium Write data transaction rate Good aggregate transfer rate Most versatile RAID level	Disk failure has a medium impact on throughput

Recommended applications for RAID 5:

- File and Application servers
- WWW, E-mail, and News servers
- Intranet servers

RAID 10

Advantages	Disadvantages
Implemented as a mirrored RAID Volume whose segments are RAID 0 RAID Volumes High I/O rates are achieved thanks to multiple stripe segments	Very high disk overhead – uses only 50% of total capacity

Recommended applications for RAID 10:

- Imaging applications
- Database servers
- General fileserver

Spare Drive

A spare is a disk drive that has been designated to replace a failed disk drive in a RAID Volume. In the event of the failure of a disk drive within a RAID 1 or three-drive RAID 5 Volume, the spare drive is activated as a member of the RAID Volume to replace a disk drive that has failed.

A spare drive cannot replace the failed drive in a RAID 0 Volume because of the way in which data is written to the disk drives under RAID 0.

A spare drive is not available for a RAID 10 Volume because RAID 10 requires all four disk drives in the EdgeStore enclosure. However, when you replace the failed disk drive, the EdgeStore will automatically rebuild the RAID Volume using the new disk drive.

You must designate a disk drive as a Spare. By default, and unassigned disk drive is Free. Use EASM to designate the Free disk drive as a Spare. See

Maintaining a spare drive is a good precaution to protect your RAID Volume integrity in the event of disk drive failure.

Automatic Rebuilding

When a disk drive in your RAID 1, 5, or 10 Volume fails, and a replacement disk drive becomes available, the RAID Volume will rebuild itself to the new disk drive automatically.

For RAID 1 and three-drive RAID 5 Volumes, you can designate a spare drive. If a spare drive is present when the RAID Volume experiences a disk drive failure, the rebuild will start automatically using the spare drive.

For RAID 1, RAID 5, and RAID 10 Volumes without a spare drive, the RAID Volume will begin to rebuild itself automatically when you remove the failed disk drive and install a new disk drive.

A RAID 0 Volume cannot be rebuilt because of the way in which data is written to the disk drives under RAID 0. Even if there is a designated spare drive, rebuilding is not possible for RAID 0 Volumes.

Partition and Format

When you create a RAID Volume on EdgeStore, the RAID Volume is automatically partitioned and formatted for you.

To use your RAID Volume, you must create Folders on the RAID Volume and assign services to those Folders according to your requirements. EdgeStore provides file services for Windows, UNIX/Linux and Macintosh, so all of those PCs can access the folders on the EdgeStore, even though each PC might have a different file system.

RAID Volume Migration

Migration is the process of:

- Changing the RAID level
- Adding disk drives but keeping the same RAID level

In the migration process, the existing RAID Volume is called the *Source*. The proposed RAID Volume is called the *Target*. Each target RAID Volume has certain requirements and they are different for each RAID level. You must meet all of the requirements in order to successfully migrate a RAID Volume.

In most cases, you must add one or more disk drives during the migration process. You can never reduce the number of disk drives.

While the migration is running, you can still access the folders on your RAID Volume and the data they contain.

The tables below shows the migration options for a source RAID Volume according to its RAID level. The available target RAID levels are shown with their requirements.

RAID 0

A RAID 0 source Volume can migrate to the following target RAID levels:

Target	Requirements
RAID 0	Add disk drives.
RAID 1	2 disk drives only. Only a 1-drive RAID 0 can migrate to RAID 1. Add 1 disk drive.
RAID 5	3 disk drives minimum. At least 1 more disk drive than the RAID 0 RAID Volume.

RAID 1

A RAID 1 source Volume can migrate to the following target RAID levels:

Target	Requirements
RAID 0	Can use same number of disk drives.
RAID 5	3 disk drives minimum. At least 1 more disk drive than the RAID 1 RAID Volume.

RAID 5

A RAID 5 source Volume can migrate to the following target RAID levels:

Target	Requirements
RAID 0	Can use same number of disk drives.
RAID 5	Add a disk drive.

RAID 10

A RAID 10 source Volume cannot migrate or add more disk drives.

Chapter 8: Troubleshooting

- Responding to an Audible Alarm (page 111)
- Checking the System Status LED (page 112)
- Checking Disk Status LEDs (page 112)
- Replacing a Failed Disk Drive (page 113)
- Checking RAID Volume Status in EASM (page 113)
- Checking File System Status in EASM (page 115)
- Checking the Event Log in EASM (page 116)
- Checking Enclosure Status in EASM (page 120)
- Resolving Connections with SmartSYNC (page 121)
- Solving Network Connection Problems (page 123)
- Restoring the Default Password (page 124)
- Resolving a Windows Firewall Issue (page 125)

This chapter deals problems you might encounter with your EdgeStore and how to resolve them. Also see “Frequently Asked Questions” on page 127.

Responding to an Audible Alarm

The EdgeStore has two beep patterns

- **Single beep, not repeated** – The EdgeStore is online
- **Two beeps, continuously repeated** – The EdgeStore reports a problem

When you boot or reboot the EdgeStore, and the buzzer is enabled, the buzzer sounds one time to indicate that the EdgeStore is online.

If you hear the two-beep pattern, check the following items:

- System Status LED (see below)
- Drive Status LED (see page 112)
- RAID Volume status in EASM (see page 113)
- File System status in EASM (see page 115)
- Enclosure status in EASM (see page 120)
- Event Log in EASM (see page 116)
- Your email inbox (see page 124)

Checking the System Status LED

The EdgeStore system status LED (see Figure 1.) reports the condition of the Enclosure fan and power supply:

- **Green** – Normal Enclosure function
- **Amber** – There is a problem with the fan or power supply
- **Red** – The fan, power supply, or file system has failed

If your EdgeStore is configured to work with a UPS, it will continue to run after a power supply failure.

Checking Disk Status LEDs

The disk status LEDs (see Figure 1.) report the condition of the disk drives:

- **Green** – Normal disk drive function
- **Amber** – Rebuilding to this disk drive
- **Red** – Failed disk drive
- **Dark** – No disk drive is installed

See “Replacing a Failed Disk Drive” on page 113.

Figure 1. EdgeStore Disk and System Status LEDs



Replacing a Failed Disk Drive

If a disk drive fails, the Disk Status LED is red. See Figure 1. If the disk drive belongs to a RAID Volume, the Volume goes Critical or Offline. See “Checking RAID Volume Status in EASM” on page 113.

Replace the failed disk drive with a new disk drive of the same or slightly greater capacity. You do not have to power down the EdgeStore.

1. Open the EdgeStore’s front door.
2. Pull out the drive carrier with the failed drive.
3. Remove the failed disk drive from the drive carrier.
4. Install a new disk drive into the carrier.
5. Place the carrier with the new disk drive back into the open slot in the EdgeStore.

If the failed drive belonged to a RAID Volume, the RAID Volume will begin rebuilding as soon as the new drive is installed.

During the Rebuild, the Disk Status LED show amber. When the Rebuild is finished, the Disk Status LED turns green.

If the replacement drive is free, that is, not assigned to a RAID Volume or as a spare, the Disk Status LED remains dark after you install the new drive.

Checking RAID Volume Status in EASM

To view RAID Volume status:

1. Start EASM.

   See “EASM in your Browser” on page 60.

   Or see “EASM in SmartSYNC” on page 61.
2. In the Tree, click the **+** beside the **RAID & File System** icon.
3. Click the **RAID Management** icon.

   The status is displayed in the **RAID Status** tab.

Figure 2. EASM reports a Critical RAID Volume



EdgeStore Responds to a Critical RAID Volume

How the EdgeStore responds to a Critical RAID Volume depends on the RAID level of your Volume and whether you have a spare drive available:

- For a RAID 1 Volume or a three-drive RAID 5 Volume, if a spare drive is available, the RAID Volume begins rebuilding itself automatically.
- For RAID 1, 5, and 10 Volumes, when no spare drive is available, you must replace the failed disk drive. The RAID Volume will begin rebuilding itself when you install the new disk drive. See “Replacing a Failed Disk Drive” on page 113.
- RAID 0 Volumes go *offline* after a disk drive failure. A RAID 0 Volume cannot be rebuilt. All data on the Volume is lost.

Additional Details about Rebuilds

- The Rebuild takes several minutes, depending on the size of your disk drives.
- During a rebuild, you can access your folders on the EdgeStore.
- When you replace the failed disk drive with a new disk drive, the new disk drive becomes a Free Drive.

Responding to an Invalid RAID Volume

The EdgeStore considers a RAID Volume *invalid* when the RAID Volume was created by a different EdgeStore. However, the RAID Volume itself remains functional and the data on it is safe.

This condition could happen when you:

- Move the disk drives from one EdgeStore to a different EdgeStore.
- Remove the disk drives in order to send your EdgeStore for service.

When the EdgeStore's memory does not recognize the RAID Volume, so EASM displays the RAID Volume as invalid. See Figure 3.

Use the Recover function to validate the RAID Volume. The Recover tab is only active when an invalid RAID Volume is present and can be recovered.

Figure 3. An invalid RAID Volume in EASM



Using the Recover Function

To validate the RAID Volume:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **RAID Management** icon.
3. Click the **Recover** tab.
4. On the **Recover** tab, click the option button beside the invalid RAID Volume.
5. Click the **OK** button.

   The EdgeStore will reboot itself to update its configuration and recognize the RAID Volume.

Important

Running the Recover function might erase some or all of your EdgeStore settings. If that condition happens, run the NAS Setup Wizard. See "Setting up the EdgeStore" on page 13.

Checking File System Status in EASM

Typically the first indication of a problem with the EdgeStore's file system is when your network drive becomes unavailable.

You might also see the message, "File system contains errors. Please check." when you click the icons under the File & Print menu.

To view File System status:

1. Start EASM.

   See “EASM in your Browser” on page 60.

   Or see “EASM in SmartSYNC” on page 61.
2. In the Tree, click the **+** beside the **RAID & File System** icon.
3. Click the **File System Management** icon.
4. Look for the RAID Volume icon on the **File System Status** tab.

   If the RAID Volume icon is Critical (has a yellow !), the file system contains errors and you must rebuild the file system. See below.

Rebuilding the File System

Caution

When you rebuild a File System, you delete all the folders in the RAID volume and all the data saved in the folders.

To rebuild a File System:

1. In the Tree, click the **+** beside the **RAID & File System** icon.
2. Click the **File System Management** icon.
3. In the **File System Status** tab, click the RAID Volume Critical icon to display the **Rebuild File System** button.
4. Click the **Rebuild File System** button.
5. In the confirmation box, type **yes** into the field provided, then click the **OK** button.

Checking the Event Log in EASM

To view the Event Log in EASM:

To check Enclosure status:

1. Start EASM.

   See “EASM in your Browser” on page 60.

   Or see “EASM in SmartSYNC” on page 61.
2. In the Tree, click the **+** beside the **Management** icon.
3. Click the **Event Log** icon.

   The Event Log displays. See Figure 4.

Figure 4. The EASM Event Log



Date / Time	Level	Message
Oct 10 00:20:49	WARNING	Array 0 created
Oct 10 00:20:43	INFO	Create (RAID-1885765) RAID0(x1).
Oct 10 00:20:34	WARNING	Array 1 deleted
Oct 10 00:20:32	INFO	Delete RAID (RAID-162004).
Oct 9 23:40:18	WARNING	Migration on array 1 completed
Oct 9 23:29:28	WARNING	Migration on array 1 90%
Oct 9 23:19:53	WARNING	Migration on array 1 80%
Oct 9 23:11:08	WARNING	Migration on array 1 70%
Oct 9 23:02:38	WARNING	Migration on array 1 60%
Oct 9 22:54:08	WARNING	Migration on array 1 50%
Oct 9 22:18:17	WARNING	Migration on array 1 40%
Oct 9 21:46:37	WARNING	Migration on array 1 30%
Oct 9 21:17:31	WARNING	Migration on array 1 20%
Oct 9 20:47:56	WARNING	Migration on array 1 10%
Oct 9 20:16:50	WARNING	Migration on array 1 started
Oct 9 20:16:44	INFO	Migrate RAID from RAID0 (x1) to RAID0 (x2)
Oct 9 20:11:15	WARNING	Array 0 deleted
Oct 9 20:11:11	INFO	Delete RAID (RAID-573793).
Oct 9 20:08:15	WARNING	Array 1 created
Oct 9 20:08:14	INFO	Create (RAID-162004) RAID0(x1).

4. Check the Event Log for reports of disk drive failure or other problems.

Responding to Events

All events are reported in the Event Log. Most events are simply reports that the EdgeStore is responding to your commands.

Many events are also reported via email. The EdgeStore's buzzer sounds for serious events that require your attention.

A list of event categories is shown below:

- File System (page 117)
- NAS Replication (page 118)
- Snapshots (page 118)
- System (enclosure) (page 118)
- Disk Drives (page 119)
- RAID Volumes (page 119)

Reported Event	Corrective Action
File System	
File system of volume X content errors! Check the system before continuing.	The file system has a problem. Reboot the EdgeStore and check file system again. If the event appears again, the file system has crashed. Rebuild the file system. See page 116.

Reported Event	Corrective Action
File system capacity usage of volume X is over 90%.	Reduce the number or size of the files or expand the volume size. See “Migrating a RAID Volume” on page 81.
File system capacity usage of volume X is 100%.	
Rebuilding file system...	The file system is being rebuild by user action.
NAS Replication	
NAS replication is completed.	NAS replication has finished. Normal.
System is busy. NAS replication is abort!	The RAID Volume is currently formatting, rebuilding, or migrating. Wait until this process is done. Then try the replication again.
System is doing another replication. NAS replication is abort!	The SmarStor is currently doing a replication. Wait until the current replication is done. Then try the second replication again.
NAS replication is failed!	There is a failed network connection between the two EdgeStores. Correct the problem and try again. See page 123.
Snapshots	
The snapshot capacity usage which timestamp is [date and time] of volume X is over 90%.	Move the snapshot volume to another storage location. Or delete the snapshot and then create a new one. See page 84.
System is busy. Snapshot creation was aborted!	The RAID Volume is currently formatting, rebuilding, or migrating. Wait until this process is done. Then try the snapshot again.
System is creating another snapshot. Snapshot creation was aborted!	The SmarStor is currently doing a snapshot. Wait until the current snapshot is done. Then try the second snapshot again.
System (enclosure)	
System is starting to work.	Normal.
System is rebooting.	
System is shutting down.	

Reported Event	Corrective Action
System was shut down abnormally.	The EdgeStore shut down incorrectly the last time. See “Shutting Down the EdgeStore” on page 98.
CPU temperature is higher than 50°C/122°F. System will shut down.	Allow the EdgeStore to cool for several minutes. Then restart the EdgeStore and check system temperature and fan operation. See page 120.
System temperature is higher than 50°C/122°F. System will shut down.	Be sure there is adequate air circulation around the EdgeStore.
System fan speed is lower than 1500 RPM. Check the system before continuing.	Replace the fan. See page 146.
AC Power failure. System will shut down.	Restore the AC power. Then restart the EdgeStore. See “Connecting the Power” on page 8.
Disk Drives	
Task X timeout on disk Y at LBA [address]	A LBA error. Check the disk drives. See page 112. Check the RAID Volume. See page 113. Replace the disk drive or rebuild the RAID Volume as needed.
Task X disk error on disk Y at LBA [address] with status Z	
S.M.A.R.T threshold exceeded on disk X	Check the disk drives. See page 112. Replace the failed drive. See page 113.
BSL update on disk X at LBA [address]	Bad sector on a disk drive. Check the disk drives. See page 112. Replace the disk drive if it continues to receive BSL updates.
BSL log disk X at LBA [address] cleared	Check the disk drives. See page 112.
Delete Spare Disk	Delete a spare drive. Normal.
RAID Volumes	
Create [RAID name, RAID level and X number of disk drives]	Create a RAID Volume. Normal.
Delete RAID X	Delete a RAID Volume. Normal.
Migration or Rebuilding on array X started.	RAID Volume Migration or Rebuild has started. Normal.
Migration or Rebuilding on array X at Y%.	Progress report on RAID Volume Migration or Rebuild. Normal.

Reported Event	Corrective Action
Migration or Rebuilding on array X paused at Y%.	RAID Volume Migration or Rebuild was paused temporarily by user action.
Migration or Rebuilding on array X resumed at Y%.	RAID Volume Migration or Rebuild was paused and then resumed by user action.
Migration or Rebuilding on array X completed.	RAID Volume Migration or Rebuild has finished. Normal.
Migration or Rebuilding on array X aborted at Y%	RAID Volume Migration or Rebuild was aborted (stopped) by user action.
Migration or Rebuilding on array X aborted at Y% because of error.	RAID Volume Migration or Rebuild has aborted (stopped) because of an error. Check the disk drives. See page 112. Check the RAID Volume. See page 113.
RAID status: “OFFLINE”. The NAS400 X volume Y is offline.	Check the disk drives. See page 112. Replace the failed drive. See page 113. Create a new RAID Volume. See page 80.
RAID status: “CRITICAL”. The NAS400 X volume Y is not functioning correctly.	Check the disk drives. See page 112. Replace the failed drive. See page 113. The RAID Volume will rebuild automatically.
RAID X had some errors. Formatting was aborted!	Check the disk drives. See page 112. Replace the failed drive. See page 113.

Checking Enclosure Status in EASM

To check Enclosure status:

1. Start EASM.
   See “EASM in your Browser” on page 60.
   Or see “EASM in SmartSYNC” on page 61.
2. In the Tree, click the **+** beside the **System** icon.
3. Click the **System Information** icon.
4. Click the **Enclosure Information** tab.
   See Figure 5.

Figure 5. The Enclosure Information tab with malfunctions shown



The corrective action you take depends on the nature of the problem:

- If CPU temperature is above specification:
  - Be sure there is adequate air flow around the EdgeStore.
  - Be sure the ambient temperature is below 35°C (95°F).
  - Check the fan speed.
- If the fan speed is below specification, contact Technical Support. See page 130.
- If any power status is out-of-specification, contact Technical Support. See page 130.

Resolving Connections with SmartSYNC

The SmartSYNC utility is designed to detect the EdgeStore on your network. If SmartSYNC does not detect your EdgeStore, check the following items:

- Be sure the EdgeStore is powered up and fully booted.

  The Power Button and System Status LED should be green. See Figure 6.
- Be sure the EdgeStore is properly connected to your network.

  The Ethernet Activity LED should be green or blinking green. See Figure 6.

  If the Ethernet Activity LED is dark, see “Solving Network Connection Problems” on page 123.
- Be sure that SmartSYNC is looking on the same network where you connected the EdgeStore.

Figure 6. Power Button, System Status and Ethernet Activity LEDs



Multiple Network Connections

If your PC has multiple network connections, you must verify that SmartSYNC is looking on the network where the EdgeStore is installed:

1. Open SmartSYNC.

   In the Windows application tray (lower right corner of the screen), double-click the SmartSYNC icon.



2. From the Option menu, choose *Scan Network Interface*.
3. In the dropdown menu, choose the IP address of the network interface card connected to the network where you installed the EdgeStore. See Figure 7.

Figure 7. Scan Network Interface in SmartSYNC



Solving Network Connection Problems

Most network connection problems are the result of poor connections.

When the EdgeStore is fully booted and connected to the network, the Ethernet Activity LED indicates status and activity:

- **Green** – Network link is properly connected
- **Flashing Green** – Network Activity
- **Dark** – No Connection

See Figure 6.

If your EdgeStore is connected to your network but the Ethernet Activity LED on your EdgeStore is dark, check the following items:

- Verify that the switch, hub, or facility network service connection that you are using is operational.

  Switches and hubs have LEDs that light when there is a connection and flash when there is activity.

  Network service connections generally do not have LEDs to verify whether they actually are connected to the network. See your Network Administrator for assistance.
- Be sure the network cable is firmly attached to the EdgeStore network connector at one end and to the network switch, hub, or facility network connection at the other.
- If the cable connections are good, remove the existing network cable and install a known-good network cable.

If you know your network devices are working properly and you know that your network cable is good, but the Ethernet Activity LED remains dark, see “Contacting Technical Support” on page 130.

Checking Your Email Inbox

If you enabled Mail Alert in EASM, the EdgeStore will send you an email message when a problem arises. Look for a message from “root.”

Figure 8. Email message from the EdgeStore.



See “Adding an Email Alert Recipient” on page 93 for more information about email alerts.

Restoring the Default Password

Normally, you change your password in EASM. See “Changing the Administrator’s Password” on page 65.

If you changed the password and then forgot the new password, you can reset the EdgeStore to the default password: **admin**. Use a straightened paper clip or the tip of a ball-point pen as a reset tool.

To reset the Administrator’s password:

1. Verify that the EdgeStore is fully booted.
2. Insert your reset tool into the reset button hole on the back of the EdgeStore.

   See Figure 9.
3. Press and hold the reset button for eight seconds, until the System Status LED flashes three times.

   The Administrator’s password is now reset to **admin**.

Figure 9. Reset button and System Status LED



Resolving a Windows Firewall Issue

If you a running a personal firewall on your Windows PC, the firewall might prevent the you from accessing the EdgeStore over your network.

Follow this procedure to add an exception for the EdgeStore:

1. From the Windows Start menu, choose *Settings*, then *Network Connections*.

   The Network Connections window opens.

2. Right-click **Local Area Connection** and choose *Properties* from the popup menu.

   The local Area Connection properties dialog box opens.

3. Click the **Advanced** tab.
4. Click the **Settings** button.

The Windows Firewall dialog box opens.

5. Click the **Advanced** tab.
6. Under Network Connection Setting, click the **Settings** button.
   The Advanced Settings dialog box opens.
7. Click the **Add** button.
   The Service Settings dialog box opens.
8. In the Description of service field, type **Edge10 NAS utility**.
9. In the Name or IP address field, type the IP address of the EdgeStore.
   See “Finding the EdgeStore’s IP Address” on page 17.
10. In the External Port field, type **49152**.
11. Click the **UDP** option button.
12. In the Internal Port field, type **49152**.
13. Click the **OK** button.

Figure 10. Windows Firewall Advanced Service Settings



14. Click the **OK** buttons in the Advanced Settings, Windows Firewall, and Local Area Connection Properties dialog boxes.

Chapter 9: Support

- Frequently Asked Questions (below)
- Contacting Technical Support (page 130)
- Limited Warranty (page 131)
- Returning Product For Repair (page 133)

Frequently Asked Questions

Also see “Chapter 8: Troubleshooting” on page 111.

The EdgeStore worked OK until I turned it off. When I turned it on again, my Windows network drive connection no longer works.

When you powered up the EdgeStore, the DHCP server assigned a different IP address to the EdgeStore. Here are two possible solutions:

- You may be able to reset the EdgeStore’s IP address manually. See “Connecting a Network Drive” on page 52 or “Making Network Settings” on page 88.

  Note that changing the EdgeStore’s IP address may cause an IP address conflict on your network. Check with your Network Administrator before taking this action.

- If you cannot restore the previous IP address, you must create new network drives and printer connections. See “Chapter 3: Connecting to the EdgeStore” on page 21.

When I start Windows, a message displays that says, “Could not reconnect all network drives.”

The EdgeStore reconnects to your PC shortly after Windows starts. In most cases, the EdgeStore network drives will be available by the time you click them.

The NAS Setup Wizard cannot access the EdgeStore over the network.

If you a running a personal firewall on your Windows PC, the firewall might prevent you from accessing folders on the EdgeStore. You must do one of the following actions:

- Disable the firewall
- Add an exception for the EdgeStore

See “Resolving a Windows Firewall Issue” on page 125.

I tried to connect my EdgeStore as a network drive using SmartSYNC, but Windows displayed an error message.

There might be an IP address conflict between the EdgeStore and another device on your network. See your Network Administrator for assistance.

I cannot log into the EdgeStore with through the AD Domain.

Be sure you use a “domain name\user name” when you log into the EdgeStore using SMB, FTP, or AFP. You must use the “\” character.

Many FTP clients do not support a space in the domain name or user name.

Also, the EdgeStore does not support a user home directory.

How does the EdgeStore integrate into an NIS Domain?

If the NIS domain account or group name is the same as the EdgeStore, the EdgeStore will apply them to its account or group.

If the EdgeStore joins a NIS Domain, joining only affects the NFS service and Quota settings. The other services are not affected.

How are non-ASCII folder file names displayed?

The EdgeStore supports Unicode, so you can use non-ASCII characters in your folder names. Windows 98 and ME do not support Unicode, so they cannot display your folder names properly. But you can still access your folders.

I tried to copy a Windows shortcut to my network drive, but an error message says there is not enough free disk space.

Normally, you can copy a Windows shortcut to a network drive. However, if the network drive is a USB drive or memory stick with FAT32 file format, the EdgeStore might not recognize the shortcut and prevent you from copying it.

If this situation occurs, choose a different folder in which to copy the shortcut.

Does EdgeStore support a USB drive or memory stick with FAT16 file format?

No. If you attach the FAT16 USB drive or memory stick to EdgeStore, you can see the files on it. But if you attempt to copy files to the drive or memory stick, Windows might display a *disk full* message.

How do I remove a USB drive or memory stick from the EdgeStore?

Be sure that no files on the USB drive or memory stick are still open. Then unplug the USB drive or memory stick from the EdgeStore. The EdgeStore automatically unmounts the USB drive or memory stick.

Can I do a One Touch Backup or a regular Backup on a protected folder or file on my Windows PC?

No. Windows does not allow SmartSYNC to access protected folders and files. If you want to perform a backup, you must first disable protection on your folders and files.

Which FTP clients are compatible with the EdgeStore's FTP server?

Edge10 recommends FTP clients that support Unicode, such as Filezilla or Smart FTP for Windows, Filezilla for Linux, and Transmit v3.5.5 for Macintosh.

If your FTP client does not support Unicode, you have two choices:

- Use only ASCII characters to name your shared folders.
- Set your EdgeStore for double-byte character encoding. See page 73.

I cannot find the DLNA Server tab under Protocol Control in EASM.

You must download and install the DLNA plug-in on your EdgeStore to access this feature. See "Installing Application Plug-ins" on page 145.

Can I move the disk drives from one EdgeStore to a different EdgeStore?

Yes. However, to access the RAID Volume on the new EdgeStore, you must run the Recover function. When EdgeStore's memory does not match the RAID Volume on the disk drives, the RAID Volume is considered *invalid* and the Recover function becomes available. See "Responding to an Invalid RAID Volume" on page 114.

I set up email alert recipients but they never receive any messages.

In most cases, you must setup SMTP authentication in order for your alert messages to pass your SMTP server. See "Setting up SMTP Authentication" on page 92.

Can EdgeStore handle jumbo frames?

Yes. But you must set the maximum frame size in EASM. See "Working with Jumbo Frames" on page 89.

Contacting Technical Support

If you decide to contact us, please have the following information available:

- Product model and serial number
- BIOS, firmware, and driver version numbers
- A description of the problem / situation
- System configuration information, including: motherboard and CPU type, hard drive model(s), SAS/SATA/ATA/ATAPI drives & devices, and other controllers.

Technical Support

Visit the Edge10 web site at www.edge10.com.

Edge10 Corporation Limited

Manchester Business Park,
3000 Aviator Way,
Manchester.
M22 5TG. UK.

Tel: + 44 (0) 871 855 01 10
Fax: + 44 (0) 871 855 21 53

UK Warranty Centre

+44 (0) 70 77 810 210
(Customer Help Line)

Limited Warranty

Edge10 Corporation Limited (“Edge10”) warrants that for three (3) years from the time of the delivery of the product to the original end user:

a) the product will conform to Edge10’s specifications;

b) the product will be free from defects in material and workmanship under normal use and service.

This warranty:

a) applies only to products which are new and in cartons on the date of purchase;

b) is not transferable;

c) is valid only when accompanied by a copy of the original purchase invoice.

d) Is not valid on spare parts, fans, and power supplies

This warranty shall not apply to defects resulting from:

a) improper or inadequate maintenance, or unauthorized modification(s), performed by the end user;

b) operation outside the environmental specifications for the product;

c) accident, misuse, negligence, misapplication, abuse, natural or personal disaster, or maintenance by anyone other than a Edge10 or a Edge10-authorized service center.

Disclaimer of other warranties

This warranty covers only parts and labor, and excludes coverage on software items as expressly set above.

Except as expressly set forth above, Edge10 DISCLAIMS any warranties, expressed or implied, by statute or otherwise, regarding the product, including, without limitation, any warranties for fitness for any purpose, quality, merchantability, non-infringement, or otherwise. Edge10 makes no warranty or representation concerning the suitability of any product for use with any other item. You assume full responsibility for selecting products and for ensuring that the products selected are compatible and appropriate for use with other goods with which they will be used.

Edge10 DOES NOT WARRANT that any product is free from errors or that it will interface without problems with your computer system. It is your responsibility to back up or otherwise save important data before installing any product and continue to back up your important data regularly.

No other document, statement or representation may be relied on to vary the terms of this limited warranty.

Edge10's sole responsibility with respect to any product is to do one of the following:

a) replace the product with a conforming unit of the same or superior product;

b) repair the product.

Edge10 shall not be liable for the cost of procuring substitute goods, services, lost profits, unrealized savings, equipment damage, costs of recovering, reprogramming, or reproducing of programs or data stored in or used with the products, or for any other general, special, consequential, indirect, incidental, or punitive damages, whether in contract, tort, or otherwise, notwithstanding the failure of the essential purpose of the foregoing remedy and regardless of whether Edge10 has been advised of the possibility of such damages. Edge10 is not an insurer. If you desire insurance against such damage, you must obtain insurance from another party.

Some states do not allow the exclusion or limitation of incidental or consequential damages for consumer products, so the above limitation may not apply to you.

This warranty gives specific legal rights, and you may also have other rights that vary from state to state. This limited warranty is governed by the State of California.

Your Responsibilities

You are responsible for determining whether the product is appropriate for your use and will interface with your equipment without malfunction or damage. You are also responsible for backing up your data before installing any product and for regularly backing up your data after installing the product. Edge10 is not liable for any damage to equipment or data loss resulting from the use of any product.

Returning Product For Repair

If you suspect a product is not working properly, or if you have any questions about your product, contact Technical Support (see page 130), making sure to provide the following information:

- Product model and serial number (required)
- Return shipping address
- Daytime phone number
- Description of the problem
- Copy of the original purchase invoice

The technician will assist you in determining whether the product requires repair. If the product needs repair, Technical Support provide you with the necessary instructions.

You are responsible for the cost of insurance and shipment of the product to Edge10. Note that damage incurred due to improper transport or packaging is not covered under the Limited Warranty.

When repairing returned product(s), Edge10 may replace defective parts with new or reconditioned parts, or replace the entire unit with a new or reconditioned unit. In the event of a replacement, the replacement unit will be under warranty for the remainder of the original warranty term from purchase date, or 30 days, whichever is longer.

Edge10 will pay for standard return shipping charges only. You will be required to pay for any additional shipping options (such as express shipping).

Appendix A: SmartWizard Advanced Mode

The SmartWizard performs the setup procedures on your EdgeStore.

To set up your EdgeStore:

1. From the Windows Start menu, choose *Programs*, then *Edge10 NAS Utility*, and then *SmartWizard*.

   The SmartWizard welcome screen appears.

2. From the Choosing a language dropdown menu, choose the language you prefer.
3. Choose an Initiation Mode.

   Click the *Express Mode* option if ALL of these conditions apply:

   - You have a DHCP server on your network with addresses available.
   - You want data protection for your disk array.
   - You want to use date and time settings from your PC.

   Express Mode is recommended for most users.

   Click the *Advanced Mode* option if one or more of these conditions apply:

   - You do not have a DHCP server on your network.
   - You have a DHCP server but no addresses are available.
   - You want to set the IP address manually.
   - You want maximum capacity (RAID 0) for your disk array.
   - You want to set date and time manually.

The rest of the setup instructions describe Advanced mode. For setup instructions using Express mode, see “Setting up the EdgeStore” on page 13.

4. Click **Next >>** to continue.

   The Discovering Edge10 NAS screen appears.



5. Highlight the EdgeStore you are initiating, then click **Next >>** to continue.

   The Login dialog box appears.



6. Type **admin** into the Password field, then click **OK**.

   The Administrator and password are case sensitive.

   The Time Zone, Date and Time screen appears.



7. From the dropdown menus, choose your:
   - Time Zone
   - Year
   - Month
   - Date
   - Time in hours (24 hour clock), minutes and seconds

   Click **Next >>** to continue.

   The Making Network Settings screen appears.


Smart Wizard
Making Network Settings
Please choose a method of making network settings.
Obtain network settings automatically from DHCP server or wizard.
Make network settings manually.
Click NEXT to continue.
<< BACK
NEXT >>
CANCEL

8. In the Making Network Settings screen, choose one of the following:
   - **Obtain network settings automatically...** – If you have a DHCP server on your network with IP addresses available, and you want the EdgeStore to obtain the network settings from the DHCP server, choose this option.
   - **Make network settings manually** – If you do not have a DHCP server, there are no addresses available, or you prefer to make your own network settings, choose this option

Important

If your DHCP server assigns the IP address to the EdgeStore, and you later restart the EdgeStore, the DHCP server might assign a different IP address.
If the EdgeStore's IP address changes, your existing network drives and printer connections will no longer work. You must then create new network drives and printer connections.

Click **Next >>** to continue.

If you chose the automatic option, the Protecting Your Data Screen appears. Skip to Step 10.

If you chose the manual option, the Making Network Settings Manually screen appears.



9. Type your entries into the fields provided:
   - Computer Name – The EdgeStore's Server Name of your choice
   - IP address
   - Subnet Mask
   - Default Gateway
   - Primary DNS
   - Secondary DNS

Note

See your Network Administrator for help in making these settings.

Edge10 suggests that you set the first three octets of the EdgeStore's IP address to match the first three octets of your PC's IP address.

After initiation, you can change your network settings in SmartSYNC or in EASM.

Click **Next >>** to continue.

The Protecting Your Data Screen appears.



10. In the Protecting Your Data screen:
    - Check the *Create new storage* box if you are setting up the EdgeStore for the first time.

      The Wizard creates a RAID array, a default volume, and a default folder called *Public*.
    - UNcheck the *Create new storage* box if you already have a RAID and file system on your EdgeStore.

      By unchecking the box the Wizard will leave your existing file system intact.

Caution

If you check the *Create new storage* box, the Wizard will delete all existing data and folders on the EdgeStore.

If you checked the *Create new storage* box, choose one of the following options:

- **Data Protection** – Creates a fault-tolerant RAID Volume on your EdgeStore. If two disk drives are installed, the Wizard creates a RAID 1 Volume. If three or four disk drives are installed, the Wizard creates a RAID 5 Volume.
- **Maximum Capacity** – Creates a RAID 0 Volume on your EdgeStore. The full combined capacity of the disk drives will be available for data

storage but there will be no fault tolerance to protect your data if one of the disk drives fails.

Click **Next >>** to continue.

The Assigning a Network Device Name screen appears.

Smart Wizard
Assigning a network device name.
The Wizard has created a shared folder "PUBLIC" for you.
Please enter a Device Name for the shared folder.
Device Name :
Z:
Click NEXT to continue.
<< BACK
NEXT >>
CANCEL

11. Select a Device Name or drive letter to represent the EdgeStore as a network drive. The list begins with Z and goes in reverse alphabetical order.

    Click **Next >>** to continue.

    The Reviewing Your Settings screen appears.



12. Review your settings and click **Finish** to begin the system initiation.

    A System Message appears.



13. In the System Message, click **OK** to finish the system initiation.

    The Wizard creates a RAID Volume and a default folder called *Public*.

    If two disk drives are installed in your EdgeStore, the Wizard creates a RAID 1 Volume. If three or four disk drives are installed, the Wizard creates a RAID 5 Volume.

    The Public folder on the EdgeStore appears under My Computer as a network drive.


My Computer
File Edit View Favorites Tools Help
Back Search Folders
Address My Computer
Name Type Total Size Free Space Commen
Hard Disk Drives
Local Disk (C:) Local Disk 37.2 GB 30.5 GB
Devices with Removable Storage
3½ Floppy (A:) 3½-Inch Floppy Disk
CD Drive (D:) CD Drive
Network Drives
public on 'NAS400 (192.168.1.110)' (Z:) Network Drive 455 GB 297 GB

    You can now copy files to and from the folder on the EdgeStore.

    To access this folder from other PCs, see “Chapter 3: Connecting to the EdgeStore” on page 21.

    To create additional RAID Volumes and folders, see “Adding a Folder” on page 76.

Appendix B: Maintenance

- Upgrading the Firmware (below)
- Installing Application Plug-ins (page 145)
- Connection Problems After Restart (page 146)

Upgrading the Firmware

Follow this procedure to upgrade the firmware on your EdgeStore.

Downloading the Upgrade File

To download the upgrade file:

1. Download the latest firmware upgrade file from www.edge10.com onto your PC.
2. Copy the firmware upgrade file from your PC to a folder on the EdgeStore.

Installing the Upgrade File

1. Start the EASM interface.
2. In the Tree, click the **+** beside the **Management** icon.
3. Click the **System Upgrade** icon.
4. From the Volume dropdown menu, choose the Volume that has the folder with the firmware image file.
5. From the Folder dropdown menu, choose the Folder that contains the firmware upgrade file.
6. In the File Name field, type the name of the firmware upgrade file.
7. Click the **OK** button to begin the upgrade.

   The upgrade takes about two to three minutes.

Warning

Do not disconnect the power or shut down the EdgeStore while the upgrade is running!

   When the upgrade is done, a system message appears.

8. Click the **OK** button on the system message.
9. Reboot the EdgeStore.

   See “Rebooting the EdgeStore” on page 144.

Rebooting the EdgeStore

During the reboot, none of your folders will be accessible from your networked PCs.

To reboot the EdgeStore:

1. In the Tree, click the **+** beside the **System** icon.
2. Click the **Reboot / Shutdown** icon.
3. Click the **Reboot** option.
4. Click the **OK** button.
5. In the confirmation box, click the **OK** button.

   The reboot runs automatically. When the EdgeStore is fully booted:

   - The System Status LED turns green (right)
   - The buzzer beeps one time (if the buzzer is enabled)

   See “Enabling and Disabling the Buzzer” on page 94.



Installing Application Plug-ins

Application plug-ins are enhancements to EdgeStore's capabilities. The DLNA server, which enables EdgeStore to support the UPnP protocol, is one example of an application plug-in.

Follow this procedure to install an application plug-in on your EdgeStore.

Downloading the Plug-in File

To download the plug-in file:

1. Download the plug-in file you want from www.edge10.com onto your PC.
2. Copy the plug-in file from your PC to a folder on the EdgeStore.

Installing the Plug-in File

1. Start the EASM interface.
2. In the Tree, click the **+** beside the **Management** icon.
3. Click the **System Upgrade** icon.
4. From the Volume dropdown menu, choose the Volume that has the folder with the plug-in file.
5. From the Folder dropdown menu, choose the Folder that contains the plug-in file.
6. In the File Name field, type the name of the plug-in file.
7. Click the **OK** button to begin the installation.

Warning

Do not disconnect the power or shut down the EdgeStore while the installation is running!

When the installation is done, a system message appears.

8. Click the **OK** button on the system message.
9. Reboot the EdgeStore.

See "Rebooting the EdgeStore" on page 144.

Connection Problems After Restart

If your EdgeStore's network settings were set to *Obtain an IP address automatically*, your DHCP server might assign a different IP address to the EdgeStore when you restart the EdgeStore after is was shutdown for repairs.

This condition does not apply if you assigned your EdgeStore's IP address manually.

If you experience network drive or printer connection failures, check the EdgeStore's current IP address. See "Finding the EdgeStore's IP Address" on page 21. If the EdgeStore's IP address has changed, your previous network drives and printer connections will no longer work.

Here are two possible solutions:

- You may be able to reset the EdgeStore's IP address manually. See "Changing the EdgeStore's Network Settings" on page 53 or "Making Network Settings" on page 85.

  Note that changing the EdgeStore's IP address may cause an IP address conflict on your network. Check with your Network Administrator before taking this action.
- If you cannot restore the previous IP address, you must create new network drives and printer connections. See "Chapter 3: Connecting to the EdgeStore" on page 25.

Appendix C: GNU General Public License

This product includes copyrighted third-party software licensed under the terms of the GNU General Public License. Please see the GNU General Public License (“GPL”) for the exact terms and conditions of this license at www.gnu.org.

The GPL source code incorporated into the product is available for free download at our web site at www.edge10.com.

Subject to GPL, you may re-use, re-distribute and modify the GPL source code. Note that with respect solely to the GPL Software, no warranty is provided, we do not offer direct support for the distribution.

Index

A

about this manual 1
action status, RAID Volume 79
AD domain 70, 128
add 80
  email alert recipient 93
  folder 64, 76
  group 67
  group member 67
  RAID Volume 80
  spare drive 81
  user 63, 65
Add Printer Wizard 34
Administrator's password, change 65
APC UPS 95
application plug-ins 145
architecture, NAS400 2
audible alarm 111
Authentication dialog box 27

B

background activity, RAID Volume 79
backup
  performing 53
  scheduling 56
backup files
  restore location 48
  restoring 47
  view 46
BACKUP folder 46, 54
backup folder
  select 54
  view 54
backup schedule
  create 44
  delete 57
  modify 57
backup server 86
backup software 4
Browser Path 12
browser support 4, 17
browser, default 58
buttons
  exit 50
  Extend File System 81
  One Touch Backup 6, 45
  open GUI 19, 50
  power 6, 121
  reset 125
buzzer
  enable/disable 94
  one beep 8
  patterns 111

C

cable, network 123
client OS support 4, 5
computer name 88, 139
Configuration Tool 12
Configure Tool 8
connection, failed after restart 127, 146
connections
  network 7, 123
  network drive 52
  power 8
  USB printer 31
connections, resolving 121
connectors
  network 6, 123
  power 6
  RJ45 6
  USB 6
  USB drive 39
counter-sink screws 7
CPU temperature 99, 121

critical RAID Volume 114

D

date and time 96, 136
date and time settings 13
DCHP server 63
DDNS 90
default browser, setting 58
default gateway 63, 88, 89, 139
delete
    device record 53
    email alert recipient 93
    folder 76
    group 68
    group member 67
    RAID Volume 82
    user 66
device name 15, 52, 141
DHCP server 13, 88, 138
disconnect USB drive 42
disk drive
    assign to RAID Volume 64
    events 119
    installing 7
    replace 113
    SATA 7
    view 80
disk drives, moving to a different EdgeStore 114
disk status LED 112
display EdgeStores on network 50
DLNA
    media formats 75
    plug-in 74, 129, 145
    server 74, 145
DNS name, SMTP server 92
DNS server 63, 88, 89, 139
domain controller 70
domain name
    AD domain 70
    DDNS 90
drive letter 44
drive record, delete 53
dynamic domain name server 90

E

EASM
    connect to 59
    connecting to 17
    default browser 58
    event log 116
    in browser 18, 60
    in SmartSYNC 19, 61
    language 62
    navigating the interface 62
    Setup Wizard 63, 101
    starting 50
EdgeStore
    cannot connect after restart 127
    enclosure info 99
    finding IP address 17
    locate 98
    reboot 97, 144
    restart 98
    shut down 20, 98
    unpacking 5
    view system info 99
EdgeStores, on network, display 50
email alert list, view 93
Email notification 124
enable One Touch Backup 87
enclosure
    events 118
    status 120
error message, network drive 128
error message, not enough free disk space 128
ESD warning 5
Ethernet activity LED 121, 123
Ethernet hub or switch 7

event log 116
clear 58
save to text file 58
view 58, 92
events
disk drive 119
enclosure 118
file system 117
NAS replication 118
RAID Volume 119
snapshots 118
system 118
events, response to 117
export access list, UNIX/Linux PC 72
Ext3 file format 39

F

failed boot drive 56
fan speed 99, 121
fans
cooling 6
power supply 6
FAT16 file format 128
FAT32 file format 39, 128
file protocol support 3
file system
events 117
rebuilding 116
status 115
files
backup 46
protected 43, 56
restore backup 47
finding EdgeStore's IP address 17
firewall, Windows 125
firmware, updating 143
folder
add 64, 76
delete 76
FTP sharing 78
folder, cont.
names 128
protected 43, 56
select for backup 44, 54
services 75
UNIX/Linux sharing 77
view 75
view backup 54
Windows sharing 77
formatting
memory stick 83
RAID Volume 80
USB drive 83
free disks 80
FTP
access setup 73
client encoding 73
clients 128, 129
sharing setup 78

G

GNU General Public License 147
group
add 67
add member 67
delete 68
delete member 67
view 66

H

hub, network 123

I

icon, SmartSYNC 19, 44, 49, 61
internal port in Windows 126
invalid RAID Volume 114, 129
IP address
EdgeStore 18, 21, 29, 60, 63, 86, 88, 89, 126, 139, 146
EdgeStore, finding 17

IP address, cont.
NIC 12
obtain from DHCP server 13, 88, 138
SMTP server 92
UNIX/Linux PC 25, 72, 77

J

jumbo frames 89, 129

L

language
configuration tool 12
EASM 62
NAS Setup Wizard 13, 135
SmartSYNC 49
LEDs
disk activity 6
disk status 6, 112
Ethernet activity 6, 121, 123
system status 6, 8, 82, 97, 98, 112, 121, 124
Linux
export access list 72
setup access 71
setup network drive 24
sharing setup 77
locate EdgeStore 98

M

Macintosh access, setup 72
Macintosh, setup network drive 27
mail alerts 124
Map Network Drive 23
maximum transmission unit (MTU) 89
media 75
media formats 75
memory stick
format 128
formatting 83
view 83
migrate a RAID Volume 81
mirror RAID 103, 106
mirror/stripe RAID 105, 107
modify folder services 75
My Network Places 21

N

NAS replication
enable/disable 86
events 118
schedule 86
setup 86
NAS Setup Wizard 12, 101
cannot access EdgeStore 127
language 13, 135
NAS Utility Installer 8
network
connecting to 7
connection problems 123
connections, multiple 122
display EdgeStores on 50
network drive
connecting 52
could not reconnect all 127
error message 128
Windows 16, 142
network drive setup
Linux 24
Macintosh 27
naming 47
UNIX 24
Windows 21
network information, view 88
Network Servers 26
network settings, making 88
Network Time Protocol (NTP) 96
networks, multiple 7, 12

NIS domain 71, 128
non-ASCII characters in folder name 128
not enough free disk space error message 128
NTP synchronization, view 97

O

One Touch Backup 6, 129
described 43
enable 43
perform 45
One Touch Backup, enable 87
OS, client supported 4

P

parity RAID 104, 107
partition and format 108
password
administrator's 63
change Administrator's 65
change user's 66
DDNS 90
EASM 18, 19, 51, 60, 61
EdgeStore 27, 29, 33, 35
NAS Setup Wizard 15, 136
NAS400 37
restore default 124
SMTP server 92
permissions, Windows 71
personal firewall 127
plug-ins, installing 145
power button 121
power status 99
power, connecting to 8
primary server 86
print server, setup 32, 74
printer, name in Linux 35
printing
Linux 34
Macintosh 37
Windows 32
protected folders and files 43, 56, 129
protocols supported 2
Public folder 16, 22, 26, 52, 142

Q

quota
set 68
view 68

R

RAID level 64, 79, 80
choosing 106
RAID 0 102, 106
RAID 1 103, 106
RAID 10 105, 107
RAID 5 104, 107
RAID level, change 81
RAID Volume 7, 13, 16, 64, 75, 76, 80, 140, 142
automatic rebuilding 108
change RAID level 109
critical 114
delete 82
events 119
formatting 80
invalid 114, 129
migrate 81, 109
partition and format 108
rebuild 114
recover 115, 129
status 113
view status 79
RAID, introduction to 101
reboot EdgeStore 97, 144

rebuild
file system 116
RAID Volume 114
recipient, email alert 129
add 93
delete 93
recover
RAID volume 115, 129
snapshot backup 85
replace
disk drive 113
resolving connections 121
restart EdgeStore 98
restore
backup files 47
location 55
performing 55
restore location, backup files 48
RJ45 connector 7

S

scan network interface 122
schedule
PC-to-EdgeStore backup 56
snapshot backup 85
select backup folder 54
server (EdgeStore) name 139
service
DDNS 90
FTP 64
Macintosh 64
UNIX/Linux 64
service status, view 91
services, enable 64
settings
network 88
quota 68
setup
FTP access 73
Linux printing 34
Macintosh access 72
setup, cont.
Macintosh printing 37
NAS replication schedule 86
print server 32
print server access 74
snapshot backup 84
UNIX/Linux access 71
UPS 95
Windows access 70
Windows printing 32
Setup Wizard in EASM 63
shared folder 52
shut down 20, 98
SmartSYNC 8, 12, 17, 121
close window 50
icon 44
language 49
open 49
quitting 50
SmartWizard 8
Advanced Mode 135
Express Mode 13
SMTP authentication 92, 129
snapshots
events 118
recover backups 85
setup backups 84, 85
status 84
view 84
software, installing 8
spare drive
add 81
explained 107
specifications 3
standalone 86
status
disk drives 112
EdgeStore 112
enclosure 120
file system 115
RAID Volume 79, 113

status, cont.
service status 91
snapshot 84
system 112
UPS 94
stripe RAID 102, 106
subnet mask 63, 88, 89, 139
switch, network 123
system
backup file 56
events 118
system status LED 8, 82, 97, 98, 112, 121, 124
system temperature 99

T

temperature, CPU 121
time zone 136

U

UDP option in Windows 126
Unicode support 129
Unicode, folder name support 128
UNIX
export access list 72
setup access 71
setup network drive 24
sharing setup 77
unpacking the EdgeStore 5
update firmware 143
UPnP protocol 74, 145
UPS 112
setup 95
view 94
USB drive
connect 39
disconnect 42
file formats 39
formatting 83
RAID Volume on 80
USB drive, cont.
view 83
Windows shortcuts 128
USB printer, connecting 31
USBDISK 39, 41, 83
user
add 63, 65
change password 66
delete 66
view 65
user name
DDNS 90
EASM 18, 19, 51, 60, 61
EdgeStore 27, 29, 33, 35
NAS400 37

V

view
backup files 46
backup folder 54
disk drive 80
email alert list 93
enclosure info 99
event log 58, 92
folders 75
group 66
memory stick 83
NAS replication schedule 86
network information 88
NTP synchronization 97
quota 68
RAID Volume status 79
service status 91
snapshots 84
system info 99
UPS status 94
USB drive 83
users 65

W

Windows
- AD domain 70
- firewall issue 125
- setup access 70
- setup network drive 21
- setup sharing 77
- workgroup 71